How to Use?

- Unpack the scissors and remove the Blade Guard. Please retain it safely for later use during storage
- Hold the scissors comfortably in your palm and push the handles together while cutting the paper
- Once done, please store the scissors safely after putting on the Blade Guard
- Do clean the scissors carefully with a soft brush and slightly damp cloth



REMEMBER

- Please do not press down excessively or beat down on the handles in case the material you are trying to cut does not give way
- The blades must not be exposed to water for too long kindly ensure you dry them thoroughly before storing
- Store it in a cool and dry place to extend the life of the blades and handles