

## How to Use?

- Unpack the scissors and remove the safety cover. Please retain it safely for later use during storage
- Place the scissors on a flat surface and find an ideal spot for yourself to be seated conveniently
- You can keep the scissors stationary and move the paper across the blades. Alternately, you can also 'scoot' the scissors forward while holding the paper straight



- Once done, please store the scissors safely after putting on the Blade Guard
- Do clean the scissors carefully with a soft brush and slightly damp cloth
- If you prefer to keep the scissors stationary while cutting, try and place it on a non-slip surface than a smooth one like glass or laminates



### REMEMBER

- Please do not press down excessively or beat down on the handles in case the material you are trying to cut does not give way

- The blades must not be exposed to water for long - kindly ensure you dry them thoroughly before storing