



Data Sheet

What is Ladder Saver?

Ladder saver is a device that can be attached to the end of a pressure washer to increase the reach distance.

How to use Ladder Saver:



1
Connect
Attach the nozzle to the quick connect gun.



2
Apply
Place siphon hose into chemical bucket to begin.



3
Rinse
Place siphon hose into bucket with clean water & rinse.

How far does Ladder Saver reach?

Ladder Saver Reach Info

Pressure Washer Class	Pressure (PSI)	Reach (ft)
Light Duty	<2000	30
Medium Duty	2000-2800	35
Heavy Duty	2900-3300	40
Extra Heavy Duty	>3300	50-60

This table illustrates the distances that can be reached when using the Ladder Saver. The reach is dependent on the PSI, GPM, and hose lengths.

WARNING: To prevent injury, read all directions for appropriate use. To prevent injury and property damage, test the connection of all pieces by spraying away from the area to check pressure prior to the start of any project. Always wear eye protection compliant with ANSI 287.1. NEVER aim the Ladder Saver nozzle at people, pets, electrical devices or pressure washing unit. ALWAYS follow appropriate MSDS sheet for chemicals used in the pressure washer.