


Instructions

Pairing and Speed:

- The remote control must be within 6 feet of the skateboard in order to connect and operate the skateboard.
- To connect them first power on the skateboard and then the remote.
- If the red “code” light on the remote blinks press the “code” button. When the light stops blinking and remains red, the remote and board are paired.
- The default setting for speed is slow. Press the speed button for the fast setting indicated by the fast blinking light below the speed button.
- Switch off the remote by pressing the power button. The remote will turn off automatically if not in use for 5 minutes.



Operating:

To operate the board, step on with your feet shoulder width apart, bend at the knees and lean slightly forward. Slide the “Acceleration & Brake” button down to go forward and slide it up to brake.

WARNING Make sure to wear protective gear while riding to avoid injury.

Charging the Remote and Skateboard:

To charge the remote use the USB cable included. Plug the USB cord into the “Charging Port.” To charge the skateboard, first plug the cable into the board and then into the wall. To reset remote, press on/off button 4 times.