

We've made it easy for you!



When prompted to empty the Freshpack bin, carefully pull the cup stand away from the brewer and set aside.



To remove the Freshpack bin, place your hand along the bottom of the bin and pull it away from the brewer.



Empty the bin into your designated **Freshpack** recycling container. Slide the Freshpack bin and cup stand back in place.

Beans and Grind Coffee Done Simply

