
# POCKET SHOT **3D**USER'S MANUAL


Before operating your edelkrone, please watch the user's manual video from the link below

http://edel.kr/ps3d













### 3. ASSEMBLY OF THE TOP PLATE (PART I)







## 5. ASSEMBLY OF THE BOTTOM PLATE (PART I)








### 7. ASSEMBLY OF THE TOP PLATE & ARM I













Magnets directly fit into their places. But, you may use adhesive if needed.

You can either hide the 1/4" mounting screw in its place or keep it on the plate. While placing the screw in its place, make sure to insert it by turning so that you could create its thread manually.



#### 11. TENSION ADJUSTMENTS



#### DISCLAIMER

edelkrone cannot be held responsible for damage caused by improper use or modification of the product.



For more information and tips about your PocketShot 3D, please watch the user's manual videos at : http://edel.kr/ps3d