

MIXX™

TRUE WIRELESS



StreamBuds™ Air 5

True Wireless Earbuds

HOW TO GUIDE

MIXX

THANKS!

Thank you for choosing to buy our MIXX StreamBuds Air 5 earbuds.

All of our products come with a 2 year warranty for peace of mind.

Feedback is welcome, email us on support@mixx-io.com for any comments or queries.

We hope you enjoy using your new earbuds.



CONTENTS

LET'S START	1
LET'S CONNECT	3
LET'S ASK GOOGLE OR SIRI	3
LET'S STAY CHARGED	4
LET'S PLAY	5
NEED EXTRA HELP?	7
TECHNICAL SPECS	8
CONTACT MIXX	8
LET'S BE SAFE	9
LET'S RECYCLE	10
SAFE USAGE INFO	41

LET'S START

What's in the box?


A pair of earbuds



One portable charging case



USB C charging cable



- 1 Left Touch Sensor
- 2 Earbud LED Lights
- 3 Right Touch Sensor
- 4 Microphones
- 5 Portable Charging Case
- 6 USB C Charging Port (Base)
- 7 LED Charge Indicator
- 8 USB C Charging Cable

LET'S CONNECT

First Time Pairing

Remove both earbuds from the Portable Charging Case **5**.

They will automatically dual pair together; a voice will prompt 'Power on, pairing' and a 'Beep' will sound. One of the Earbud LED Lights **2** will flash WHITE to indicate pairing mode. If the earbuds do not automatically dual pair together, **tap each earbud** 4 times to power off and then place them both back into the case. Remove the earbuds and they should automatically dual pair together.

Go to the Bluetooth settings on your audio device and select 'MIXX StreamBuds Air 5' from the list. Once paired successfully you will hear 'Connected' and the Earbud LED Light **2** will turn off.

You can now enjoy your music, watch a video or take a call hands free.

The earbuds will automatically reconnect to the last device they were paired with, confirming 'Connected'.

Placing both earbuds back in the Portable Charging Case **5** will power them off.

LET'S ASK GOOGLE OR SIRI

Pair your Bluetooth device with your earbuds.

Triple tap either Touch Sensor **1** or **3** to activate Siri or Google Assistant.

Your Voice Assist familiar 'Beep' will sound to confirm connection.

You can now ask Siri or Google Assistant a question or state a command.

LET'S STAY CHARGED

The Earbuds

A voice prompt 'Battery low' allows for 2 minutes play time before the earbud(s) powers down stating 'Battery low, power off'. The Earbuds LED Light **2** will flash WHITE once and will then switch off. Charge the earbuds using the Portable Charging Case **5**.

While charging, each Earbud LED Light **2** will be WHITE and once fully charged the LED Lights **2** will turn off. Secure the earbuds by closing the lid.

TIP: 15 MINUTE QUICK CHARGE

If you're running low on power, charge your earbuds for 15 minutes and get **2 hours extra play time** while on the go

The Portable Charging Case

When LED Indicator **7** flashes WHITE after closing the charge case lid, it is time to recharge.

Always connect the case to a suitable USB wall charger, computer USB port or a power bank using the USB C charging cable **8** supplied.

The charge light indicator **7** will flash RED during charging, and will then light up solid RED once the charge case is fully charged.

LET'S PLAY



First Time Pairing

Remove both earbuds from the charging case.

Go to the Bluetooth settings on your audio device to select 'MIOX StreamBuds Air 5' from the list.

Once paired successfully you will hear 'Connected'.

Play / Pause

Double tap either Touch Sensor **1** or **3**.

Decrease Volume

Single tap LEFT Touch Sensor **1**

Increase Volume

Single tap RIGHT Touch Sensor **3**

Previous Track

Tap and hold **LEFT** Touch Sensor **1**

Skip Track

Tap and hold **RIGHT** Touch Sensor **3**

Answer / End Call

Double tap either Touch Sensor **1** or **3**.

Activate Siri or Google Assistant

Triple tap either Touch Sensor **1** or **3** to activate Siri or Google Assistant. Listen for the familiar Voice Assist 'Beep' then ask a question or state a command.

Power on

Remove both earbuds from the case. They will automatically turn on and dual pair together. A voice prompt will state 'Connected' as confirmation. To manually turn on, **long press** each Touch Sensor **for 3 seconds**.

Power off

Place both earbuds in the case and close the lid. This will automatically turn off the earbuds and the Bluetooth.

NEED EXTRA HELP?

Common solutions

If you are experiencing problems with your earbuds:

- Power on the earbuds (see page 6).
- Check the status on the LED Lights (see page 3).
- Charge the earbuds (see page 4).
- Move your device closer to the earbuds and away from any obstructions or interference.
- Try connecting to another device.

Question & Answers

- Q.** While pairing with my phone, I see two 'MIXX StreamBuds Air 5' in my Bluetooth menu listing?
- A.** One of the Earbud LED Lights will flash WHITE, wait approximately 4 seconds for the earbuds to connect to each other before pairing with your device.
- If there is still no connection simply 'forget' or 'unpair' both earbuds in your Bluetooth settings, place them back in the case and start again.
- Q.** How do I turn on my earbuds without using the charging case?
- A.** **Long press for 3 seconds** both Touch Sensors to manually turn them on.
- Q.** Can I use the earbuds individually?
- A.** Yes, you can use one earbud while leaving the other in the case to charge. Swap them over when the earbud in use, loses its charge.
- Q.** What smartphone voice assist systems do these earbuds work with?
- A.** Connects with Siri, Google Assistant or Bixby (depending on your device).

LET'S VIEW TECHNICAL SPECS

Play time on a single charge:	Up to 4.5 hours
Play time with charging case:	Up to 18 hours
Bluetooth:	Version 5.1
Resistance:	IPX5, water and dust resistant
Supported profiles:	HSP, HFP, A2DP, AVRCP
Wireless range:	10m
Earbud capacity:	30mAh each side
Charge case capacity:	300mAh
Dynamic driver:	10mm
Frequency response:	20Hz – 20KHz
Weight including case:	Total 43.4g (earbuds 3g each)
Portable case dims:	59 x 52 x 24mm

Compatibility

Suitable for most Bluetooth audio supported smartphones, tablets, notebooks, laptops and computers.

CONTACT MIXX

Feedback is welcome simply email us on support@mixx-io.com or visit mixxaudio.com for more information.

LET'S BE SAFE

It's important that you read this section completely, especially the '**Warning, Caution and Safe Usage**' instructions.

For your protection

Ensure the product is correctly connected using the manufacturer's original accessories included with the product.

Please keep the product out of reach from children and animals.

Do NOT listen to loud music for a long duration of time.

- We recommend turning down the volume before placing the device in or on your ears.
- Adjust the volume to a comfortable level before listening to avoid hearing damage.

Do NOT use the product while operating machinery, including cars, trucks or other vehicles.

Do NOT use noise cancelling mode or use your device in areas where the use of hearing is required for safety. e.g., while riding a bicycle, at a construction site or railroad etc.

Do NOT drop, short circuit, disassemble or continue to use this product and its portable charging case if damaged.

CAUTION!

Please remove your device from your ears immediately if:

- * They emit any loud unusual noise
- * You experience a warming sensation
- * There is loss of audio

Turn off your device and contact MIXX Limited on **support@mixx-io.com**.

IMPORTANT!

Do NOT use a non-certified PD or QC3 wall charger as this may damage the product. Only use the cable supplied to charge your device.

May contains small parts which may be a choking hazard. NOT suitable for children under age 6.

We recommend

To refer all servicing to qualified persons. Servicing may be required when the product has been damaged in any way, does not operate normally or has been dropped.


WARNING: The operating temperature range for this product is 5° - 40° celsius.

Please avoid exposing the product, charging case and cable connectors to prolonged rain, moisture, any splashing or liquid spills.

This may cause excessive heat or melting and may lead to fire damage or personal injury.

CAUTION: This product contains a Lithium battery. Incorrect disposal of this battery may result in an explosion.

LET'S RECYCLE

This product can be recycled.  Products bearing this symbol must NOT be thrown away with normal household waste.

Take the product to a collection point designated for recycling of electronic devices.

Find out more about return and collection points through your local authority.

A top-down view of various electronic accessories on a dark grey surface. In the upper left, a black USB-A to USB-C cable is partially visible. In the center-left, a black rectangular power bank is shown, featuring a small digital display showing '5.5V' and the text 'Powerbank 30' and 'Power Charge 30'. To the right, a white braided USB-C to USB-C cable is coiled. In the bottom center, another black USB-A to USB-C cable is shown. In the top right, a portion of a dark laptop is visible. In the middle right, a black smartphone is partially shown.

MIXX™

CHARGE

To view our wide range of
power banks, chargers, cables
and in-car products, visit us on

mixxcharge.com



SAFE USAGE INFO

Do not crush, puncture or incinerate the charging case or the earbuds.
Only use certified or device manufacturer's charging cable.

MIXX



support@mixx-io.com



mixxaudio.com

MIXX Limited
5 The Pavilions, Brighton Road, Pease Pottage,
West Sussex, RH11 9BJ. United Kingdom

SBA5-HTG02