

MIXX®

StreamBuds™ ColourChroma 1 True Wireless Earbuds

QUICK START GUIDE



MIXX

THANKS!

Thanks for choosing our MIXX StreamBuds ColourChroma 1 earbuds.

All of our products come with a 2 year warranty for peace of mind.

Feedback is welcome, email us on support@mixx-io.com for any comments or queries.






CONTENTS

LET'S START	1
LET'S STAY CHARGED	2
LET'S CONNECT	3
LET'S PLAY	4
LET'S ASK GOOGLE/SIRI	5
LET'S RECYCLE	5
LET'S BE SAFE	6

LET'S START

What's in the box?



LET'S STAY CHARGED

Note: If your earbuds and charge case do not have any power when you first unpack them, place the earbuds into the charge case and plug the charge case into a USB port using the USB C cable **8** provided.

The Earbuds

A voice prompt **"Battery low"** allows for 2 minutes play time before the earbud(s) powers down stating **"Battery low, power off"**. The Earbuds LED Light **2** will flash WHITE once and will then switch off. Charge the earbuds using the Portable Charging Case **5**.

While charging, each Earbud LED Light **2** will be WHITE and once fully charged the LED Lights will turn off. Secure the earbuds by closing the lid.

When the earbuds are placed inside the case and the lid is closed, the charge indicator light **7** will glow green for 4 seconds to show it is charging and then turn off.

TIP: 15 MINUTE QUICK CHARGE

If you're running low on power, charge your earbuds in the case for 15 minutes and get **2 hours extra play time** while on the go

The Portable Charging Case

Always connect the case via the USB C port **6**, to a suitable USB wall charger, computer USB port or a power bank using the USB C charging cable **8** supplied. Plug the supplied cable into the USB C port **6** on the charge case.

The charge light indicator **7** will blink RED, on and off, to show the case is charging.



LET'S CONNECT

First time pairing

Remove both earbuds from the Portable Charging Case **5**.

They will automatically dual pair together; a voice will prompt **"Power on, pairing"** and a 'Beep' will sound. One of the Earbud LED Lights **2** will flash WHITE to indicate pairing mode. If the earbuds do not automatically dual pair together, **tap each earbud 4 times** to power off and then place them both back into the case. Remove the earbuds and they should automatically dual pair together.

Go to the Bluetooth settings on your audio device and select **'MIXX ColourChroma 1'** from the list. Once paired successfully you will hear **"Connected"** and the Earbud LED Light **2** will turn off.

You can now enjoy your music, watch a video or take a call hands free.

The earbuds will automatically reconnect to the last device they were paired with, confirming **"Connected"**.

Placing both earbuds back in the Portable Charging Case **5** and closing the lid will power them off. (note – if the earbuds do not turn off, the battery in your charging case needs to be recharged – see 'Let's Stay Charged.'

LET'S PLAY

Power on

Remove both earbuds from the case. They will automatically turn on and dual pair together. A voice prompt will state **"Connected"** as confirmation. To manually turn on, **long press** each Touch Sensor **for 3 seconds**.

Power off

Place both earbuds in the case and close the lid. This will automatically turn off the earbuds and the Bluetooth.

Play / Pause

Double tap either Touch Sensor **1** or **3**

Increase Volume

Single tap RIGHT Touch Sensor **3**

Decrease Volume

Single tap LEFT Touch Sensor **1**

Previous Track

Tap and hold LEFT Touch Sensor **1**



Skip Track

Tap and hold RIGHT Touch Sensor **3**

Answer / End Call

Double tap either Touch Sensor **1** or **3**.
(Audio is picked up via the microphones **4**.)


LET'S ASK GOOGLE ASSISTANT / SIRI

Triple tap either Touch Sensor  or  to activate Siri or Google Assistant.

Your Voice Assist familiar 'Beep' will sound to confirm connection. You can now ask Siri or Google Assistant a question or state a command.

LET'S RECYCLE

This product can be recycled.

Products bearing this symbol  must NOT be thrown away with normal household waste.

Take the product to a collection point designated for recycling of electronic devices.

Find out more about return and collection points through your local authority.

LET'S BE SAFE

IT IS IMPORTANT THAT YOU PLEASE READ THIS SECTION COMPLETELY.

For your protection

Check with your doctor before use if you are fitted with a medical device such as a pacemaker or a programmable shunt.

Ensure the product is correctly connected using the manufacturer's original accessories included with the product.

Do NOT make unauthorized alterations to this product.

Product may contain small parts which can be a choking hazard. Please keep the product out of reach from children under 6 and animals.

Whilst this product has been made using hypo-allergenic materials, you may suffer some skin irritation after prolonged use.

Do NOT listen to loud music for a long duration of time. We recommend turning the volume down before placing the device in your ears to avoid hearing damage.

Do NOT use the product while operating machinery, including cars, trucks or other vehicles.

Do NOT use noise cancelling mode or use your device in areas where the use of hearing is required for safety. e.g., while riding a bicycle, at a construction site or railroad etc.

Clean only with a dry cloth - Wipe off sweat from the earbuds and the charging case before charging.

IMPORTANT!

Do NOT use a non-certified PD or QC3 wall charger as this may damage the product. Only use the cable supplied to charge your device.

If your product has become damaged in any way, does not operate normally or has been dropped, please refer to a qualified person to have the product checked before continuing to use it.

WARNING:

This product contains a Lithium battery. Incorrect disposal of this battery may result in an explosion.

The operating temperature range for this product is 5° - 40° celsius.

Please avoid exposing the product, charging case and cable connectors to prolonged rain, moisture, or liquid spills/splashing.

Please remove your device from your ears immediately if they emit any loud unusual noise or you experience a warming sensation.

If you experience any of the issues listed above, please turn off your device and contact MIXX Ltd on support@mixx-io.com

MIXX



support@mixx-io.com



mixxaudio.com

MIXX Limited

5 The Pavilions, Brighton Road, Pease Pottage,
West Sussex, RH11 9BJ. United Kingdom