

MIXX™

TRUE WIRELESS ANC



StreamBuds™ Micro ANC

True Wireless Noise Cancelling Earbuds

HOW TO GUIDE

MIXX

THANKS!

Thank you for choosing to purchase our Mixx StreamBuds Micro ANC.

All products brought to you by MIXX Limited come with a 2 year warranty for peace of mind.

Feedback is welcome, email us on support@mixx-io.com for any comments or queries.

We hope you enjoy using your new earbuds.



CONTENTS

LET'S START	1
LET'S CONNECT	3
LET'S USE ACTIVE NOISE CANCELLING (ANC) AND TRANSPARENT MODES	5
LET'S ASK GOOGLE OR SIRI	6
LET'S STAY CHARGED	7
LET'S PLAY	9
NEED EXTRA HELP?	11
CONTACT MIXX	12
LET'S VIEW TECHNICAL SPECS	13
LET'S BE SAFE	15
LET'S RECYCLE	16
SAFE USAGE INFO	17

LET'S START

What's in the box?

A pair of earbuds





- 1 Left Touch Sensor
- 2 Earbud LED Lights
- 3 Right Touch Sensor
- 4 Microphones
- 5 Portable Charging Case
- 6 Case LED Charge Light
- 7 USB C Charging Port (Base of the case)
- 8 USB C Charging Cable
- 9 3 Pairs of Ear Cushions (S, M and L)

LET'S CONNECT

First time pairing



"Power on, pairing"

Remove both earbuds from the Portable Charging Case **5**.

They will automatically dual pair together, a voice prompt will say 'Power on, pairing' and a 'Beep' will sound.

One of the Earbud LED lights **2** will flash BLUE and WHITE to indicate pairing mode.

Go to the Bluetooth settings on your audio device to select 'MIXX StreamBuds ANC' from the list. Once paired successfully you will hear 'Connected' and the Earbud LED Light **2** will turn off.

You can now enjoy your music, watch a video or take a call hands free.

The earbuds will automatically reconnect to the last device they were paired with, confirming 'Connected'.

Placing both earbuds back in the Portable Charging Case **5** will power them off.

For a secure fit



Choose from the 3 different ear sized cushions supplied, small, medium (currently on earbuds) or large that are most comfortable for your ears.

TOP TIP: Remember to keep the ear cushions clean to maintain good quality sound.

LET'S USE ACTIVE NOISE CANCELLING (ANC) AND TRANSPARENT MODES



How does ANC work?

The innovative technology inside these noise cancelling wireless earbuds monitors the surrounding background noise, and generates an inverted sound wave to cancel out the surrounding noise. This creates a much quieter environment for the user.

How does Transparent Mode work?

Transparent mode effectively does the opposite of ANC – the wireless earbuds amplify the surrounding sound allowing you to stay aware of your environment despite your ears being effectively blocked by the earbuds.

Activating ANC and Transparent Modes

Double tap the RIGHT Touch Sensor **3** to cycle through the following modes: ANC ON > TRANSPARENT MODE ON > ANC OFF.

Each time you **double tap** the RIGHT Touch Sensor **3** you will hear a voice announcement telling you which mode you are in, 'ANC on, Transparent mode on, and ANC off'.

LET'S ASK GOOGLE OR SIRI

Triple tap the RIGHT Touch Sensor **3** to activate Siri or Google Assistant. Your Voice Assist familiar 'Beep' will sound to confirm connection. You can now ask Siri or Google Assistant a question or state a command.

LET'S STAY CHARGED

The Earbuds

A voice prompt 'Battery low' allows for 2 minutes play time before the earbud(s) power down stating 'Battery low, power off'. The Earbuds LED Light **2** will flash WHITE once and will then switch off.

Charge the earbuds using the Portable Charging Case **5**.

While charging, the Earbud LED Lights **2** will be WHITE and once fully charged the LED Lights will turn off.

Secure the earbuds by closing the lid.

TIP: 15 MINUTE QUICK CHARGE

If you're running low on power, charge your earbuds for 15 minutes and get **2 hours extra play time** while on the go



The Portable Charging Case

Ensure that one or both earbuds are inside the Portable Charging Case **5** to check the battery status of the case. Remove the earbuds then place them back into the case.

When the case LED Charge Light **6** flashes WHITE for 5 seconds or does not light up then, it is time to recharge the Case.

Connect the case to a suitable USB wall charger, computer USB port or a power bank using the USB C charging cable **8** supplied.

The case LED Charge Light **6** will flash WHITE while charging and will then remain a solid WHITE once the case is fully charged.

Charging the case may take up to 2 hours.



LET'S PLAY



TOP TIP: For better noise isolation, comfort and sound quality ensure the correct sized (S, M or L) ear cushions (supplied) are fitted on the earbuds.

First Time Pairing

Remove both earbuds from the charging case.

Go to the Bluetooth settings on your audio device to select 'MIXX StreamBuds ANC' from the list.

Once paired successfully you will hear 'Connected'.

Play / Pause

Press and hold for 1 second either Touch Sensor **1** or **3**.

Decrease Volume

Single tap LEFT Touch Sensor **1**.

Increase Volume

Single tap RIGHT Touch Sensor **3**.

Activate ANC and Transparent Modes

Double tap RIGHT Touch Sensor **3** to cycle through the following modes: ANC ON > TRANSPARENT MODE ON > ANC OFF.

Answer / End call

Press and hold for 1 second either Touch Sensor **1** or **3**.

Decline an incoming call

Double tap either Touch Sensor **1** or **3**.

Activate Siri or Google Assistant

Triple tap RIGHT Touch Sensor **3** to activate Siri or Google Assistant. Listen for the familiar Voice Assist 'beep' then ask a question or state a command.

Power On

Remove both earbuds from the case and they will automatically dual pair together. To manually turn on, **press and hold for 4 seconds** each Touch Sensor.

Power Off

Place both earbuds in the case and close the lid. This will automatically turn off the earbuds and the Bluetooth.

To manually turn off, **press and hold for 4 seconds** each Touch Sensor.

NEED EXTRA HELP?

Common solutions

If you are experiencing problems with your earbuds:

- Power on the earbuds (see page 10).
- Check the status on the LED Lights (see page 4).
- Charge the earbuds (see page 7).
- Move your device closer to the earbuds and away from any obstructions or interference.
- Try connecting to another device.

Question & Answers

Q. What does ANC mean?

A. Active Noise Cancelling - The earbuds use noise-cancelling microphones to reduce unwanted background noise. As if you are listening to your music in a sound proof room.

Q. What does transparent mode mean?

A. Your earbuds will allow some outside sound in, so you can hear what's going on around you. Useful for hearing announcements at train stations or airports and any traffic noise.

- Q. While pairing with my phone, I see two 'MIXX StreamBuds ANC' in my Bluetooth menu listing?
- A. One of the Earbud LED Lights will flash BLUE and WHITE, wait approximately 4 seconds for the earbuds to connect to each other before pairing with your device.

If there is still no connection simply 'forget' or 'unpair' both earbuds in your Bluetooth settings, place them back in the case and start again.

- Q. How do I turn on my earbuds without using the charging case?
- A. **Press and hold for 4 seconds** both Touch Sensors to manually turn them on.
- Q. Can I use the earbuds individually?
- A. Yes, you can use one earbud while leaving the other in the case to charge. Swap them over when the earbud in use, loses its charge.
- Q. What smartphone voice assist systems do these earbuds work with?
- A. Connects with Siri, Google Assistant or Bixby (depending on your device).

CONTACT MIXX

Feedback is welcome simply email us on support@mixx-io.com or visit mixxaudio.com for more information.

LET'S VIEW TECHNICAL SPECS

Noise Reduction Rate:	About 22dB
Built-in:	ANC and Transport modes
Play time (ANC On):	Up to 4.5 hours
Play time (ANC Off):	Up to 5 hours
Play time using case (ANC On):	Up to 25 hours
Play time using case (ANC Off):	Up to 27 hours
Bluetooth:	Version 5.1
Supported Profiles:	A2DP, AVRCP, HFP, HSP
Wireless Range:	10m
Dynamic Driver:	10mm
Impedance:	16 Ohm
Sensitivity:	95dB at 1KHz
Frequency Range:	20Hz – 20KHz
Earbud Capacity:	40mAh
Charging Case Capacity:	400mAh
Connector:	Type C
Weight including case:	Total 38g (earbuds 4g each)
Case Dims:	60 x 50 x 28 mm (L x H x D)

Compatibility

Suitable for most Bluetooth audio supported smartphones, tablets, notebooks, laptops and computers.



LET'S BE SAFE

It's important that you read this section completely, especially the **'Warning, Caution and Safe Usage'** instructions.

For your protection

Ensure the product is correctly connected using the manufacturer's original accessories included with the product.

Please keep the product out of reach from children and animals.

Do not listen to loud music for a long duration of time.

Adjust the volume to a comfortable level before listening.

Do not use the earbuds while operating machinery, including cars.

Do not use in areas where the use of hearing is required for safety.

Do not drop, short circuit, disassemble or continue to use this product and its portable charging case if damaged.

IMPORTANT: Do not use a laptop power adapter or charger to charge these earbuds - as it may cause damage to the product.

We recommend

To refer all servicing to qualified persons. Servicing may be required when the product has been damaged in any way, does not operate normally or has been dropped.

The operating temperature range for this product is 5° - 40° celsius.


WARNING: Please avoid exposing the earbuds, charging case and cable connectors to prolonged rain, moisture, any splashing or liquid spills.

This may cause excessive heat and may lead to fire damage or personal injury.

CAUTION: This product contains a Lithium battery. Incorrect disposal of this battery may result in an explosion.

LET'S RECYCLE

This product can be recycled.

Products bearing this symbol  must NOT be thrown away with normal household waste.

Take the product to a collection point designated for recycling of electronic devices. Find out more about return and collection points through your local authority.

A top-down view of various electronic accessories on a grey surface. A black power bank is on the left, a black USB cable is at the bottom, and a white braided cable is on the right. A smartphone is partially visible on the right side.

MIXX™

CHARGE

To view our wide range of
power banks, chargers, cables
and in-car products visit us at

mixxcharge.com

SAFE USAGE INFO

Do not crush, puncture or incinerate the charging case or the earbuds.
Only use certified or device manufacturer's charging cable.

INFORMATION DE SÉCURITÉ

Ne pas écraser, percer ou incinérer le boîtier de chargement ou les écouteurs. Utilisez uniquement un câble de charge certifié ou du fabricant du périphérique.

INFORMATIONEN ZUR SICHEREN NUTZUNG

Brechen, durchstechen und verbrennen Sie die Ohrhörer nicht. Benutzen Sie nur zertifizierte oder vom Hersteller mitgelieferte Ladekabel.

MIXX



support@mixx-io.com



mixxaudio.com

MIXX Limited
5 The Pavilions, Brighton Road, Pease Pottage,
West Sussex, RH11 9BJ. United Kingdom

SBANC-HTG01

