

# MIXX™

TRUE WIRELESS



## StreamBuds™ ColourChroma 2 True Wireless Earbuds

HOW TO GUIDE

# MIXX

## THANKS!

Thank you for choosing to buy our MIXX StreamBuds ColourChroma 2 earbuds.

All of our products come with a 2 year warranty for peace of mind.

Feedback is welcome, email us on [support@mixx-io.com](mailto:support@mixx-io.com) for any comments or queries.

We hope you enjoy using your new earbuds.



# CONTENTS

|                          |    |
|--------------------------|----|
| LET'S START              | 1  |
| LET'S CONNECT            | 3  |
| LET'S ASK GOOGLE OR SIRI | 3  |
| LET'S STAY CHARGED       | 4  |
| LET'S PLAY               | 5  |
| NEED EXTRA HELP?         | 7  |
| TECHNICAL SPECS          | 8  |
| CONTACT MIXX             | 8  |
| LET'S BE SAFE            | 9  |
| LET'S RECYCLE            | 10 |
| SAFE USAGE INFO          | 41 |


# LET'S START

## What's in the box?


A pair of earbuds



One portable charging case



USB C charging cable



- 1 Left Touch Sensor
- 2 Earbud LED Lights
- 3 Right Touch Sensor
- 4 Microphones
- 5 Portable Charging Case
- 6 USB C Charging Port (Base)
- 7 LED Charge Indicator
- 8 USB C Charging Cable

# LET'S CONNECT

## First Time Pairing

**Remove both** earbuds from the Portable Charging Case **5**.

They will automatically dual pair together; a voice will prompt 'Power on, pairing' and a 'Beep' will sound. One of the Earbud LED Lights **2** will flash WHITE to indicate pairing mode. If the earbuds do not automatically dual pair together, **tap each earbud** 4 times to power off and then place them both back into the case. Remove the earbuds and they should automatically dual pair together.

Go to the Bluetooth settings on your audio device and select 'MIXX ColourChroma 2' from the list. Once paired successfully you will hear 'Connected' and the Earbud LED Light **2** will turn off.

You can now enjoy your music, watch a video or take a call hands free.

The earbuds will automatically reconnect to the last device they were paired with, confirming 'Connected'.

**Placing both** earbuds back in the Portable Charging Case **5** will power them off.

# LET'S ASK GOOGLE OR SIRI

Pair your Bluetooth device with your earbuds.

**Triple tap** either Touch Sensor **1** or **3** to activate Siri or Google Assistant.

Your Voice Assist familiar 'Beep' will sound to confirm connection.

You can now ask Siri or Google Assistant a question or state a command.

# LET'S STAY CHARGED

## The Earbuds

A voice prompt 'Battery low' allows for 2 minutes play time before the earbud(s) powers down stating 'Battery low, power off'. The Earbuds LED Light **2** will flash WHITE once and will then switch off. Charge the earbuds using the Portable Charging Case **5**.


While charging, each Earbud LED Light **2** will be WHITE and once fully charged the LED Lights will turn off. Secure the earbuds by closing the lid.

When the earbuds are placed inside the case and the lid is closed, the charge indicator light **7** will glow green until the earbuds inside are fully charged and the indicator light turns off.

## The Portable Charging Case

Always connect the case to a suitable USB wall charger, computer USB port or a power bank using the USB C charging cable **8** supplied.

The charge light indicator **7** will blink RED, on and off, to show the case is charging.



### TIP: 15 MINUTE QUICK CHARGE

If you're running low on power, charge your earbuds for 15 minutes and get **2 hours extra play time** while on the go

## LET'S PLAY



### First Time Pairing

**Remove both** earbuds from the charging case.

Go to the Bluetooth settings on your audio device to select 'MIXX ColourChroma 2' from the list.

Once paired successfully you will hear 'Connected'.

### Play / Pause

**Double tap** either Touch Sensor **1** or **3**

### Decrease Volume

**Single tap LEFT** Touch Sensor **1**

### Increase Volume

**Single tap RIGHT** Touch Sensor **3**



### Previous Track

Tap and hold **LEFT** Touch Sensor **1**

### Skip Track

Tap and hold **RIGHT** Touch Sensor **3**

### Answer / End Call

**Double tap** either Touch Sensor **1** or **3**.

### Activate Siri or Google Assistant

**Triple tap** either Touch Sensor **1** or **3** to activate Siri or Google Assistant. Listen for the familiar Voice Assist 'Beep' then ask a question or state a command.

### Power on

**Remove both** earbuds from the case. They will automatically turn on and dual pair together. A voice prompt will state 'Connected' as confirmation. To manually turn on, **long press** each Touch Sensor **for 3 seconds**.

### Power off

**Place both** earbuds in the case and close the lid. This will automatically turn off the earbuds and the Bluetooth.

# NEED EXTRA HELP?

## Common solutions

If you are experiencing problems with your earbuds:

- Power on the earbuds (see page 6).
- Check the status on the LED Lights (see page 3).
- Charge the earbuds (see page 4).
- Move your device closer to the earbuds and away from any obstructions or interference.
- Try connecting to another device.

## Question & Answers

- Q.** While pairing with my phone, I see two 'MIXX ColourChroma 2' in my Bluetooth menu listing?
- A.** One of the Earbud LED Lights will flash WHITE, wait approximately 4 seconds for the earbuds to connect to each other before pairing with your device.
- If there is still no connection simply 'forget' or 'unpair' both earbuds in your Bluetooth settings, place them back in the case and start again.
- Q.** How do I turn on my earbuds without using the charging case?
- A.** **Long press for 3 seconds** both Touch Sensors to manually turn them on.
- Q.** Can I use the earbuds individually?
- A.** Yes, you can use one earbud while leaving the other in the case to charge. Swap them over when the earbud in use, loses its charge.
- Q.** What smartphone voice assist systems do these earbuds work with?
- A.** Connects with Siri, Google Assistant or Bixby (depending on your device).

## LET'S VIEW TECHNICAL SPECS

|                               |                                |
|-------------------------------|--------------------------------|
| Play time on a single charge: | Up to 4.5 hours                |
| Play time with charging case: | Up to 18 hours                 |
| Bluetooth:                    | Version 5.1                    |
| Resistance:                   | IPX5, water and dust resistant |
| Supported profiles:           | HSP, HFP, A2DP, AVRCP          |
| Wireless range:               | 10m                            |
| Earbud capacity:              | 30mAh each side                |
| Charge case capacity:         | 300mAh                         |
| Dynamic driver:               | 10mm                           |
| Frequency response:           | 20Hz – 20KHz                   |
| Weight including case:        | Total 43.4g (earbuds 3g each)  |
| Portable case dims:           | 59 x 52 x 24mm                 |

### Compatibility

Suitable for most Bluetooth audio supported smartphones, tablets, notebooks, laptops and computers.

## CONTACT MIXX

Feedback is welcome simply email us on [support@mixx-io.com](mailto:support@mixx-io.com) or visit [mixxaudio.com](http://mixxaudio.com) for more information.

## LET'S BE SAFE

It's important that you read this section completely, especially the '**Warning, Caution and Safe Usage**' instructions.

### For your protection

Ensure the product is correctly connected using the manufacturer's original accessories included with the product.

Please keep the product out of reach from children and animals.

Do NOT listen to loud music for a long duration of time.

- We recommend turning down the volume before placing the device in or on your ears.
- Adjust the volume to a comfortable level before listening to avoid hearing damage.

Do NOT use the product while operating machinery, including cars, trucks or other vehicles.

Do NOT use noise cancelling mode or use your device in areas where the use of hearing is required for safety. e.g., while riding a bicycle, at a construction site or railroad etc.

Do NOT drop, short circuit, disassemble or continue to use this product and its portable charging case if damaged.

### CAUTION!

Please remove your device from your ears immediately if:

- \* They emit any loud unusual noise
- \* You experience a warming sensation
- \* There is loss of audio

Turn off your device and contact MIXX Limited on **support@mixx-io.com**.

### **IMPORTANT!**

Do NOT use a non-certified PD or QC3 wall charger as this may damage the product. Only use the cable supplied to charge your device.

May contains small parts which may be a choking hazard. NOT suitable for children under age 6.

### **We recommend**

To refer all servicing to qualified persons. Servicing may be required when the product has been damaged in any way, does not operate normally or has been dropped.


**WARNING:** The operating temperature range for this product is 5° - 40° celsius.

Please avoid exposing the product, charging case and cable connectors to prolonged rain, moisture, any splashing or liquid spills.

This may cause excessive heat or melting and may lead to fire damage or personal injury.

**CAUTION: This product contains a Lithium battery. Incorrect disposal of this battery may result in an explosion.**

## **LET'S RECYCLE**

This product can be recycled.  Products bearing this symbol must NOT be thrown away with normal household waste.

Take the product to a collection point designated for recycling of electronic devices.

Find out more about return and collection points through your local authority.

A top-down view of various electronic accessories on a dark grey surface. In the upper left, a black USB cable is plugged into a black power bank. The power bank has a small digital display showing '3.5V' and the text 'Powerbank 30' and 'Output Charge 30'. To the right, a white braided USB cable is coiled with a white strap. In the bottom right, a black smartphone is partially visible. The background is a dark grey surface with a white diagonal line.

# MIXX™

CHARGE

To view our wide range of  
power banks, chargers, cables  
and in-car products, visit us on

[mixxcharge.com](http://mixxcharge.com)



## SAFE USAGE INFO

Do not crush, puncture or incinerate the charging case or the earbuds.  
Only use certified or device manufacturer's charging cable.

## INFORMATION DE SÉCURITÉ

Ne pas écraser, percer ou incinérer le boîtier de chargement ou les écouteurs. Utilisez uniquement un câble de charge certifié ou du fabricant du périphérique.

## INFORMATIONEN ZUR SICHEREN NUTZUNG

Brechen, durchstechen und verbrennen Sie die Ohrhörer nicht. Benutzen Sie nur zertifizierte oder vom Hersteller mitgelieferte Ladekabel.

# MIXX



[support@mixx-io.com](mailto:support@mixx-io.com)



[mixxaudio.com](http://mixxaudio.com)

MIXX Limited  
5 The Pavilions, Brighton Road, Pease Pottage,  
West Sussex, RH11 9BJ. United Kingdom

SBCC2-HTG01