

SMARTWATCH



Watch¹ Colour Screen HOW TO GUIDE



SMARTWATCH

THANKS

Thank you for choosing to buy our MIXX Watch¹.

All products brought to you by MIXX Limited come with a 2 year warranty for peace of mind.

Feedback is welcome, email us on support@mixx-io.com for any comments or queries.

IMPORTANT!

Please DO NOT pair the MIXX Watch¹ using the Bluetooth settings on your phone.

Please scan the QR Code or enter URL bit.ly/WoFit download to install the

FREE WoFit App on your phone.



Pair your watch with your phone using this App.

WoFit supports iOS 9.0 or later, and Android 4.4 or later.

We hope you enjoy using your Watch¹.

CONTENTS

LET'S START	1
LET'S INSTALL THE APP	3
LET'S PAIR THE APP TO YOUR WATCH	4
LET'S LINK TO 🤍 Apple Health	5
LET'S LINK TO 💎 Google Fit	5
LET'S STAY CHARGED	6
LET'S ADJUST THE SCREEN	7
LET'S PLAY	7
LET'S VIEW TECHNICAL SPECS	16
CONTACT MIXX	16
LET'S BE SAFE	17
LET'S RECYCLE	18
NEED EXTRA HELP?	18
EXEMPTION NOTES	19
WARRANTY NOTES	19



TOUCH BUTTON

Swipe/tap to navigate options.

When further options are available, a down arrow will appear. **Touch and hold** the Touch Button, wait for green line animation to complete and the further options will display.





IMPORTANT!

Please ensure the Watch¹ is **dry** before charging



LET'S INSTALL THE APP

Please follow the instructions as numbered:

- Scan the QR Code to <u>download</u> the free WoFit App on to your smartphone.
- **2. Tap the WoFit icon W** to <u>install</u> the App and then **tap** to <u>open</u>.



- **3.** Follow the on-screen instructions to <u>register</u> and to <u>set-up an account</u>.
- Login to the App and follow the on-screen instructions. You should see the home screen.

Note: The WoFit APP **W** supports iOS 9.0 or later, Android 4.4 or later and Bluetooth 5.0.

You require Android 4.4 or Apple iOS 9.0 and later to pair with this App. Only one smartphone can be paired to the Watch¹. To pair other mobile phones, please **unbind** the current phone before pairing.

LET'S PAIR THE APP TO YOUR WATCH

IMPORTANT!

Please install the App and follow the instructions as numbered:

- 1. Tap the device icon to activate the device screen.
- 2. Tap 'Add new device,' to find the Watch¹ in device list.
- 3. Accept the App instructions for location permission.
- Select 'MIXX Watch' on your phone. You should see a 'Please confirm on the device' message on your screen.
- Once paired you will see an infinity symbol on your Watch¹ screen. You should now be successfully paired with your Watch¹.



NOTE: Please DO NOT try to pair your MIXX Watch¹ using the Bluetooth settings on your phone. Unpair with your phone's Bluetooth settings and start from the 'IMPORTANT!' message above.

To UNBIND, **tap** the device icon select your device and choose **Cancel pairing** from the bottom of the list of options.

LET'S LINK TO... Vpple Health

- 1. Open the WoFit app
- 2. Tap the 'Mine' icon to reveal your settings.
- 3. Select 'Connect via 3rd Party Platform platform'.
- 4. Select connect to 'Apple Health'.
- 5. Open your Apple Health app and tap your profile picture.
- 6. In your Apple Health profile select: Apps in your privacy settings.
- 7. Select 'WoFit' from the list.
- 8. Finally, activate the categories that you want WoFit to track.



- 1. Open the WoFit app
- 2. Tap the 'Mine' icon to reveal your settings.
- 3. Select 'Connect via 3rd Party Platform platform'.
- 4. Select connect to 'Google Fit'.
- 5. Choose a Google account to connect your WoFit app.
- 6. Allow WoFit to access your Google account
- 7. WoFit is now connected to your Google Fit app.

LET'S STAY CHARGED

Pull the top watch strap off. This may be stiff to begin with and needs to be pulled with some force to detach. Over time this should become easier.



The blue USB connector **5** will be now be exposed. This can be connected to a USB port to charge the device. The Device will buzz once to signify it is charging.



IMPORTANT!

Please ensure the Watch¹ is **dry** before charging

LET'S ADJUST THE SCREEN

ADJUST SCREEN BRIGHTNESS

From the App, **tap** on Device. Under the Display section, select Brightness Adjustment. From here you can choose the default setting or use slider to adjust the brightness of your screen.

ACTIVATE SCREEN USING WRIST ROTATION

From the App, **tap** Device. Under the Display section, turn on "Light up display by rotating your wrist". Once switched on, you can move your wrist or arm to activate (wake up) the screen on your Watch¹.

LET'S PLAY

Adjust the watchstrap so that it is a snug fit on your wrist (not too tight or loose) and there is no green light coming through from the LED light under the body of the watch.

Touch and hold the Touch Button **2** to turn the Watch¹ on/off.

Tap/swipe the Touch Button to navigate through the options. Whenever you find the down arrow, touch and hold the Touch Button to open additional options.





Tap/swipe to navigate through the 6 workouts. There is a return icon at the end of the list of workouts to enable you to return to the main menu. To select a workout, **touch and hold** the Touch Button again to open the options for that workout.

2. EXERCISE DATA

A detailed breakdown of your progress and achievements can be seen via the App on your phone by tapping on the desired feature for more information.



From the Watch¹ home screen **tap/swipe** to locate the or icon. The Watch¹ will show your steps count for the day so far.

You can see more step data by **tapping** the Steps icon (s) on the App home screen on your phone .






REMEMBER! To wear your Watch¹ to bed to capture your sleep patterns.

From the Watch¹ home screen **tap/swipe** to locate the G icon. From here you will see your previous nights total sleep displayed on your Watch¹ screen.

You can see more details of your sleep pattern including a break down of light and deep sleep by **tapping** the Sleep icon (2) on the App home screen on your phone.





From the Watch¹ home screen **tap/swipe** to locate the oicon. The Watch¹ will show your BPM heart reading.

You can see more data of your heart rate on the App by **tapping** the Heart rate icon the App home screen on your phone.





6. TEMPERATURE

From the Watch¹ home screen **tap/swipe** to locate the origination icon. Your current temperature will be displayed on your Watch¹ screen. You can see more data of your temperature pressure by **tapping** the Temperature icon on the App home screen on your phone.



7. OTHER FUNCTIONS



To locate additional functions, navigate from the Watch¹ home screen by **tapping or swiping** the Touch Button 2 until you reach the More icon 3 . The down arrow signifies more options are available. To view the extra options, **touch and hold** the Touch Button. Wait for the green line to complete it's animation and a new set of option will become available to **tap/swipe** through.



MORE MENU OPTIONS:

- 1. Stopwatch
- 2. Find cellphone
- 3. Info
- 4. Power off
- 5. Reset
- 6. Return

To navigate back to the main level of options, **tap/swipe** the Touch Button until you see the return arrow **(()**. You will need to **touch and hold** the Touch Button again to return to the main options level.

STOPWATCH

From the More menu (B) locate the stopwatch icon (1). Touch and hold the Touch Button (2) to start the timer. Tap the Touch Button to pause/ continue the timer.

Hold and press the Touch Button to return to the More menu list of options.



8. FEATURES FROM YOUR PHONE



You will need to make sure permissions are allowed on your phone. In the App select your device, then 'Notifications'. From here you can choose which Apps have permission to send notifications to your Watch¹.



From the Watch¹ home screen, **tap/swipe** to locate your messages then **touch and hold** the Touch Button to open your messages. You can view the first 6 lines of each message/ notification.

Tap/swipe to navigate through each message/notification. The Watch¹ will buzz to alert you of a new message/notification.



REMOTE CAMERA

On the phone App, **select your device**. Then scroll to the option: 'Rotate Wrist to Take Photo'.

The camera on your phone will open and the screen on your Watch¹ will change to the Photograph screen o

Set up your phone to point at the desired subject and use your Watch¹ to take the photo by either: tapping the screen on your Watch¹ or rotating your wrist.



Your Watch¹ photos will be automatically saved to a new album on your phone.



On the phone App, **tap** the device icon. **Select** the Watch¹ from the device list and scroll down the list of options to the Alarms icon **()**. From here you can access any existing alarms you may have set up, or set up a new alarm. Your Watch¹ will buzz when the alarm is activated.

9. WATCH SETTINGS

CHANGE THE WATCH FACE

From the home screen, **touch and hold** the Touch Button until the green line completes it's animation. You can then **tap/ swipe** the Touch Button to view a selection of 5 screen displays. **Touch and hold** on your chosen display to set this to your Watch¹ home screen.

You can upload additional watch face options from the App onto your Watch¹: in the App, select your device and then **tap** the Watch Face Style to show infographic or photographic watch face options.

There are 5 pre-set faces loaded on the watch, you can add 1 face from the "watch face icon" menu on the App.





10. WATCH¹ NAVIGATION

MAIN MENU

From the Watch¹ home screen, **tap/swipe** the Touch Button **2** to view the main menu functions.



MAIN MENU:

- 1. Steps (see p9)
- 2. Sleep (see p9)
- 3. Heart rate (see p10)
- 4. Temperature (see p10)
- 5. Messages (see p12)
- 6. More menu (see p11)
- 7. Workouts (see p8)

MORE FEATURES

Use the App to switch on the features outlined below to receive these reminders from your watch.

- 1. Set goals set yourself personal goals for: steps, fat reduction and sleep.
- 2. Sedentary alert sets a reminder for you to move about This is handy if you sit in a chair all day.
- 3. Incoming call turn this feature on and follow the on screen instructions so that you can obtain notifications on your watch.

LET'S VIEW TECHNICAL SPECS

Watch strap length: Watch strap width: Weight: Battery: Waterproof rating: 240 mm 20 mm 32g (including strap) 210mAh Poly-Li IP68

CONTACT MIXX

Feedback is welcome simply email us on **support@mixx-io.com** or visit **mixxwatch.com** for more information.

LET'S BE SAFE

It's important that you read this section completely, especially the 'Warning, Caution and Safe Usage' instructions.

For your protection

Ensure the product is correctly connected using the manufacturer's original accessories included with the product.

Please keep the product out of reach from children and animals.

IMPORTANT!

Do NOT use a non-certified PD or QC3 wall charger as this may damage the product. Only use the cable supplied to charge your device.

May contains small parts which may be a choking hazard. NOT suitable for children under age 6.

Allergy information:

Please note that it is your responsibility to be aware of any allergies you may have to metals and / or other materials that may be present in this product including, but not limited to: gold, silver, nickel, steel, painted surfaces, silicon, rubber or plastic. As there is no way for us to know of any allergies you may have, we will not accept liability for any allergic reaction that may occur because of wearing and / or using our products.

NOTE:

If your product has become damaged in any way, does not operate normally or has been dropped, please refer to a qualified person to have the product checked before continuing to use it.

WARNING: The operating temperature range for this product is 5° - 40° Celsius. Please avoid exposing the product and cable connectors to prolonged rain, moisture, any splashing or liquid spills. This may cause excessive heat or melting and may lead to fire damage or personal injury.

CAUTION: This product contains a Lithium battery. Incorrect disposal of this battery may result in an explosion.

LET'S RECYCLE

This product can be recycled. Products bearing this symbol must NOT be thrown away with normal household waste.

Take the product to a collection point designated for recycling of electronic devices. Find out more about return and collection points through your local authority.

NEED EXTRA HELP? Q&A

Q. My heart-rate signal seems to be missing?

A. If your Watch¹ is not showing a heart rating then the data will appear as a dotted line.

Please confirm if you are wearing the watch correctly and that the strap is not too loose or too tight. The watch strap should ideally sit back one finger width from your wrist. Not too high and not too low on your wrist or arm. After adjusting the watch please do the following:

- From the Home Screen **()** tap/swipe to the heart rate screen on the Watch¹ to obtain a manual reading.
- Check the heart rate monitor feature is turned on in the App. You should see a reading of your heart rate.
- Q. I'm having trouble pairing my Watch¹ with my smartphone?
- A. Try the following solutions:
- Check the Watch¹ is not paired with another mobile device. Please **unbind** it from the App to unpair the watch (See page 4).
- Go to LET'S INSTALL THE APP section (See page 3) and follow the steps.
- IOS device users should go to their Bluetooth settings, 'unpair' or 'forget' this device and pair it again.

EXEMPTION NOTES

 The Heart rate data output or results by the Watch¹ or App are not intended to be used on a medical or diagnostic basis.

2. Self-diagnosis and self-treatment are dangerous. Only qualified doctors are allowed to diagnose and treat heart diseases. Please contact your doctor for professional diagnostic opinions and help.

3. The data and information of heart rate provided by the Watch¹ may not be completely accurate and may exceed the tolerance as per the specification stated in the manual due to many factors, such as interference of the signal from external sources, incorrect wearing position and changes in weather conditions or user's body condition.

4. D0 N0T adjust any of your medication or therapeutic schedule based on the results output by the Watch¹. Please follow the doctor's instructions before taking any treatment or medication.

The manufacturer disclaims all liability arising from such inaccuracy and assumes no responsibility for the consequences of use of such data and information.

WARRANTY NOTES

We offer a 2 year warranty period for the Watch¹. If there is any damage or malfunction during normal use, the warranty service will be provided to the customer for free after confirmation by our technician.

The following conditions are not covered by the warranty:

- A. Accidental or deliberate damage
- B. Damage caused by disassembly or unauthorised attempt at repair
- C. Contamination of the charging connectors or sensors
- D. Damage caused by connection with equipment which is not compatible
- E. Allergic reaction to any materials contained within the product
- F. Damage caused by force majeure

MIXX

To view our extensive wireless range of Headphones, True Wireless Earbuds, Earphones and Speakers simply visit us at **mixxaudio.com**

MIXX





support@mixx-io.com

mixxwatch.com

MIXX Limited 5 The Pavilions, Brighton Road, Pease Pottage, West Sussex, RH11 9BJ. United Kingdom

W1-HTG02