



06 CIVIC FRONT




Remove
Dust Boot
And Discard




Factory
Upper Mount


Stock Bearing Is
Press Fit Onto
Factory Upper Mount





Factory
Bearing




Supplied
Aluminum
Top Hat




Remove Cap
And Discard




CUT STOCK
BUMP STOP AND
REUSE LARGER
UPPER PORTION



O-Ring



GC Spring
Discard
Stock Spring



Threaded
Sleeve

Adjustable
Spring Perch

GROUND CONTROL

www.groundcontrolstore.com

3885 Dividend Drive

Shingle Springs, CA 95682

(530)677-8600 fax (530)677-9090