## OPTIONAL REMOVAL OF STOCK SPRING PERCH

CUT TO REMOVE PERCH. **USE CAUTION NOT TO** CUT INTO STRUT TUBE.

DO NOT REMOVE WELD. KEEP ABOUT 1/8" TO 1/4" OF MATERIAL WITH WELD.

**USE REMAINING WELD** LEFT FROM PERCH TO SUPPORT STEEL RING.

## SROUND CONTROL

www.groundcontrolstore.com 3885 Dividend Drive Shingle Springs, CA 95682 (530)677-8600 fax (530)677-9090

STOCK SPRING PERCH MAY BE REMOVED TO ACCOMMODATE STEEL RING ALLOWING CAR TO BE LOWERED AND MORE TIRE **CLEARANCE** 

