

E46 & E36 OUTER BALL JOINT REPLACEMENT

← CASTLE NUT

← STUD

← SPACER

← SPACER

← BEARING HOLDER

← BMW ARM

← BEARING HOLDER LID

← SPACER

← NYLOC NUT

← ALLEN BOLTS
SECURES BEARING HOLDER TO ARM

PRESS BEARING HOLDER INTO ARM AND SECURE LID WITH ALLEN BOLTS FIRMLY HOLDING ASSEMBLY INTO ARM

