BALLOON SAND WHEEL CONVERSION KIT



PARTS LIST	
Qty	Name
2	Balloon Wheels
2	Axle Converter
2	Axle Locking Pin
2	Quick-Release Pin
1	Air Pump

Holds up to 200 LBS

Assembly

- 1. Remove existing airless wheels from cart frame.
- 2. Slide *Axle Converter* over existing axle. Secure with *Axle Locking Pin* so that *Pin* hangs down.
- 3. Inflate *Balloon Wheels* with the included *Air Pump*. When inflated, wheel has a diameter of 12" to 13". It will feel soft, that is why it works well in sand.
- 4. Slide *Balloon Wheel* over converted axle then insert a *Quick-Release Pin* in hole next to wheel and flip the lock ring over the end of the axle to secure the wheel in place.
- 5. Repeat process for other side of the cart.

Note: If wheels are "plowing sand" instead of riding over the sand, inflate wheels an additional 3 to 5 pumps.

Rev. 11/18

FOR TECHNICAL ASSISTANCE OR REPLACEMENT PARTS: CALL 866.787.7369

OUR PLEDGE TO YOU

Suspenz® products are warrantied for life against defects in material or workmanship to the original owner. Product must be used for its intended purpose under normal conditions. Please visit www.Suspenz.com for complete warranty information.

SUSPENZ®, INC. 8725 Roswell Road #0-220 Atlanta GA 30350



CUSTOMER SERVICE:770-518-0045 FAX: 770-518-8507 WEBSITE: WWW.SUSPENZ.COM