

BIG CATCH SLING ADJUSTMENT

...Free the sling if it gets jammed on the BIG CATCH Work Station (Model #55-0130)

Jam 1: Unable to Open the Stand?

When attempting to unfold the stand, the sling gets stuck and unable to rotate on padded frame. Close stand back to its original upright position and adjust sling per photo in "The FIX".



Jam 2: Sling not Fully Opened?

When the stand is unfolded, the sling gets caught and folds over itself not allowing the sling to fully open. Fold the stand back to its original upright position and adjust sling per photo in "The FIX".



What's Happening?

Sometimes during transport (or initial shipment in the box), the sling will rotate on the padded frame such that it is angled outwards as shown in photo below.



The FIX:

To free the jammed sling, close the stand back to the original upright position. It is now easy to rotate the sling so that it is angled towards the center. The stand will now unfold easily.



Rotate Sling
to the Inside
of Frame.