

The MIN, MAX, I.R, and C.L. dials must be set as shown on the Control Board diagram above.

GRANITE 1300 CLASIC SERIES SMITHY COMPANY	110 VOLT WIRE DIAGRAM	ORIGINAL DRAWN BY: DEW DATE: 07/12/10	REVISION 0 DRAWN BY: DATE:	Page 1 of 1