


M I K O

IBUKI+ AIR PURIFIER S

User Manual

MA-04WBN



READ AND SAVE THESE INSTRUCTIONS AND WARNINGS

FAILURE TO COMPLY WITH THE WARNINGS LISTED BELOW MAY RESULT IN ELECTRIC SHOCK OR SERIOUS INJURY.






This product should be used only in accordance with the specifications outlined in this manual. Usage other than what has been specified here may result in serious injury.

ATTENTION!

- **IMPORTANT** - This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
- To avoid fire or shock hazard, plug the appliance directly into the right AC electrical outlet.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves or heaters.
- The power plug must be connected in such a way as to avoid risks if the humidifier is tipped over or liquid is spilled.
- To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use near water.
- Children cannot recognize the hazards associated with the usage of electrical appliances. For this reason, always supervise children when they are near the unit.
- Always unplug the air purifier before moving it, opening the grill, changing filters, cleaning or whenever the air purifier is not in use. Be sure to pull by the plug and not the cord.
- NEVER drop or insert any object into any openings.
- DO NOT run cord under carpeting.

- DO NOT cover cord with throw rugs, runners, or similar coverings.
 - DO NOT route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
 - DO NOT operate any appliance with a damaged cord or plug, if motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Send to Customer Service for assistance.
 - Use appliances only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to person.
 - DO NOT use outdoors.
 - DO NOT place anything on top of unit.
 - NEVER block the air openings, grills/outlets or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outtake opening.
 - DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
-
- **WARNING:** To reduce the risk of fire or electric shock, do not use this device with any solid-state speed control device.
 - **WARNING:** UV radiation is dangerous for the eyes and skin. This appliance contains a UV-C emitter/lamp. Unintended use of the appliance or damage to the housing may result in the escape of dangerous UV-C radiation. UV-C radiation may, even in little doses, cause harm to the eyes and skin. Appliances that are obviously damaged must not be operated. UV-C Lamp is non-replaceable by the user, the user must not attempt to replace the UV-C lamp. The UV-C emitter must only be replaced by a qualified service/ maintenance person.

GET TO KNOW IBUKI+



PRIOR TO FIRST USE

1. Carefully lift your air purifier from box and remove the two packed plastic bags from unit and filter.
2. Select a firm, level and flat location for the air purifier.
3. Plug the power cord into a right voltage AC outlet.
4. For proper air flow, locate the unit at least 1 foot from any wall or furniture.
5. Make sure none of the grills are blocked.

HOW TO OPERATE THE MYST



POWER



FAN SPEEDS ————— Low / Med / High

AUTO

AUTO ————— Ibuki+ monitors environment and maintains it to a perfect air quality



TIMER ————— 2hrs / 4hrs / 8hrs / Turn off.



SLEEP ————— Long press (2s) to enter sleep mode. Press any button to wake up.



CHILD LOCK ————— Press to lock/unlock the buttons



WIFI ————— Long press to turn on Ibuki's wifi



FILTER RESET ————— Lights on when filter lifetime is up. After change filter, long press 3 secs to reset.

PAIR IBUKI+ WITH YOUR PHONE

Before Pairing

- Make sure your phone is connected to WIFI and bluetooth is on during pairing.
 - Long press WIFI button for 5 seconds to turn on Ibuki+ 's WIFI. The button blinks while WIFI is on and ready for connection.
1. Download "My Miko app" and register/log in your account.
 2. Select "add device" and add Ibuki+ to your Miko app.
 3. Follow the instructions on the app to pair with your phone.
 4. Select Ibuki+ on app's device list. Now you can operate and schedule Ibuki+, and monitor qir quality on your phone anytime anywhere.

INSTALLING & REMOVING FILTERS

- The FILTER icon lighting up on red indicates that it is time to replace the filter. Follow the instruction below to change filter and reset the program.

Remark:

- Remember to tear off the packing bag of the new filter before replacing it.
 - Combination Filter will last approximately 6 months.
1. Upside down the machine.
 2. Flip the unit, then rotate and lift the base cover.
 3. Change the used filter to new filter.
 4. Reattach the base to the unit.
 5. Reset the filter timer by filter reset button.

HOW TO CLEAN IBUKI+

- The machine should be cleaned at least once every month by a clean, dry, soft cloth.
- More frequent cleaning may be required depending on environmental conditions.

NOTE:

- Do NOT stick any foreign objects or your fingers inside of the unit.
- Do NOT use gasoline, benzine, thinner, harsh cleaners, etc. on and/or in the unit while cleaning as they will damage the product.
- NEVER use alcohol or other solvents.

TECHNICAL DATA

Model number: MA-04WBN

Product model: Miko IBUKI+ Air Purifier S

Power supply: 110V/60Hz

Power consumption: 15.6W

Dimensions: 210*206*312 mm/ 8.3*8.1*12.3 in

Weight: 2.3 kgs / 5 lbs

CORRECT DISPOSAL OF THIS PRODUCT



Please dispose of this product after its service life pursuant to the Waste Electrical and Electronic Equipment Directive 2012/19/EU- WEEE. The symbol on the product or its packaging indicates that this product cannot be treated as normal household waste but must be returned to a collection point for recycling electrical and electronic products.



M I K O

For all comments, questions or complaints reach out to us:

hello@shopmiko.com

www.shopmiko.com

+1-866-201-9816

