

Warning

Do not pour water on the handpiece directly, or it will damage the machine!



MINI HUMIDIFIER

Model : KS-JSQ02
Power: 2W
Voltage: DC-5V
Weight: 122g
Container: 280ml
Covering area: 1-6 m²

INNOKA

MINI HUMIDIFIER

OWNER'S MANUAL

Attention

Do not use this unit WITHOUT water



MODEL : KS-JSQ02

PLEASE DO NOT ADD PERFUME AND ESSENTIAL OIL IN WATER

IMPORTANT INSTRUCTIONS

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS.

1. Please use DC~5V power adapter.
2. Please use cold or room temperature water.
3. Please do not touch the atomizer plate with sharp objects.
4. Please do not make the machine working without water or it will shorten its service life or damage the machine.
5. If the power cord is damaged, please send to the professional staff to repair, do not repair it by yourself.
6. If not use the product for more than 3 days, please pull out the USB power line.

7. **DISPOSAL:** Do not dispose electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information. If electrical appliances are disposed in landfills, or dumps, the hazardous substances can leak into the groundwater and damage your health and well-being.



PART FIGURE



OPERATING INSTRUCTION

1. Fill the cup with water, then put the humidifier into the cup.
2. Please connect the machine to a USB power source (the light is in red), the machine is on standby.

3. Press on/off switch key, the light will turn blue, the machine starts to work and make mist.

4. A new machine or a machine not used for long time usually needs three minutes to release mist because the cotton bar needs some time to absorb water.

5. A new machine or a machine not in use for more than 30 days, we suggest to take out the cotton bar and put its 2 ends into water for about 30 seconds. When it is wet, put it back into the machine and turn on.

6. If need to stop humidification, please press the on/off switch key, the light will turn red, the machine is on standby. If need to power off, just pull out the USB plug.

TROUBLE CLEARING

When the machine is in trouble, please check several points as below:

1. Please check if the machine is connected to the USB power source;

2. Make sure if use the right standard adapter.

3. If the atomizer plate is blocked, please use a wet cotton bud to clean it.

CLEANING AND MAINTENANCE

1. Please use soft cloth to clean the machine, don't use petrol or other organic solvent. It is forbidden to put the whole machine into water.

2. After using for 30 times or 30 days, please clean it accordingly: Turn it off and take out the power cord, then get it out of the water cup and open it, take out the cotton bar and put to a dry & ventilated place. Please use soft brush to clean the water absorption hole.

3. Please use soft cloth to clean the machine surface.

4. Replace the cotton bar: hold the machine with one hand, twist the head part anticlockwise and open with another hand. Please take out the old cotton bar and put the new one wetted into the body part, then assemble the head part clockwise. See the drawing at side.

