

INNOKA

## MINI HUMIDIFIER

USER MANUAL

### Attention

Do not use high purified & distilled water.



MODEL : KS-JSQ07

PLEASE DO NOT ADD PERFUME AND ESSENTIAL OIL IN WATER


### MINI HUMIDIFIER

Model : KS-JSQ07  
Power:2W  
Voltage:DC-5V  
Weight:184g  
Container:180ml  
Covering area: 1-6 m<sup>2</sup>

### IMPORTANT INSTRUCTIONS

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS.

1. Please use DC-5V power adapter.
2. Please not use hot water or boiled water .
3. Please do not touch the atomizer plate with sharp objects.
4. Please do not make the machine working without water or it will shorten its service life or damage the machine.
5. If the power cord is damaged, please send to the professional staff to repair,do not repair it by yourself.
6. If not use the product for more than 3 days, please pull out the USB power line.

7.  **DISPOSAL:**Do not dispose electrical appliances as unsorted municipal waste, use separate collection facilities.Contact you local government for information.If electrical appliances are disposed in landfills,or dumps, the hazardous substances can leak into the groundwater and damage your health and well-being.

### PART FIGURE



### OPERATING INSTRUCTION

1. Fill the cup with water. Please keep water below the maximum water line.
2. Please plug the power line to the USB socket,and connect to the right adapter, car USB port, or computer, the machine is on standby.

3. Press on/off switch, the status light will turn blue,it starts working.Press the switch key again,the light will turn red,it changes to intermittent mist mode.Under this condition, it will make mist for 10 seconds then stop mist, after 10seconds it can make mist for 10 second again.

4. A new machine or a product not in use for long time usually needs 1or 2 minutes to release mist because the cotton bar needs time to absorb water.

5. Please pull out the cotton bar and soak the 2 ends in water, then put into the machine and turn it on.

6. To turn off the machine, just press the switch key for 3 times.

### TROUBLE SHOOTING

When the machine is in trouble, please check the below points:

1. Please check if the power adapter has been connected to the machine;
2. Make sure if the adapter is right.
3. Please make sure that there is enough water in the cup.

4. Please check if the atomizer plate is blocked,if yes, use a wet cotton bud to clean the atomizer plate.

5. Check if the cotton bar has been polluted or aging seriously. If yes, please replace the cotton bar and clean the water absorption hole at the bottom.

### CLEANING AND MAINTENANCE

1. Please use soft cloth to clean the machine,don't use petrol or other organic solvent. Do not put the whole machine into water.
2. After using for 30 times or 30 days,please clean it accordingly:Turn it off and pull out the power cord. Remove the engine part and twist the cotton bar cover,take the cotton bar to a dry ventilated place.Please use soft brush to clean the water absorption hole.
- 3.Please clean the machine surface with soft cloth and pack in the box, put in a dry place.
- 4.Replace the cotton bar: Please rive the main engine anticlockwise to remove, twist the cotton bar cover anticlockwise, it will open. Then take out the cotton bar to replace. After putting the new cotton bar, please assemble it.See the drawing at side:

