




PLEASE NOTE:
All acrylic parts have protective film applied on both sides.

Some pieces appear with opaque film, this will need to be removed before assembly.

INSTRUCTIONS FOR: LEGO® Star Wars™ UCS Luke Skywalker's Landspeeder™ Display Case



- A - Addon
- B - Baseplate
- C - Case Lid
- D - Case Front
- E - Case Back
- F - Case Side (x2)
- G - Cubes & Screws (10 boxes)
- H - Stem & Support Stem (x2)
- I - Information Plaque

If you purchased a case with a background the **Case Back** will be black.

