



iMod Installation

Switch-plate




Bell type push buttons only
Wire directly to QS iMod module



LED INDICATOR




Button Linking:




To unlink a button: Repeat steps 2&3.



BATTERY REPLACEMENT




BUTTON OPERATION




iMod Installation

Switch-plate




Bell type push buttons only
Wire directly to QS iMod module



LED INDICATOR




Button Linking:



To unlink a button: Repeat steps 2&3.



BATTERY REPLACEMENT



BUTTON OPERATION

