





NORMAL BUTTONS



Button Linking:



To unlink a button: Repeat steps 2&3.

Scene Saving:

