






THREE INPUT DOOR SENA



DOOR SENA INSTALLATION NOTES



- Mount DIN rail receiver in DB board.
- For best signal strength antenna must be mounted out of DB board housing.
- Antenna must never be cut.



BATTERY REPLACEMENT

