Jug

Smart indicator replace method



Preparation before replace









Jug which need to change the indicator

New indicator
(need to press 6s by your
nail to check it work or not
)
B


Tools
whatever tools with
sharp
C



Check the new indicator



Check new indicator have two buckling part



Take off the old indicator





Frist press one side buckling part by tool

Α


Press another side ,now the indicator is off from lid



Old indicator is off from the lid



After you press two sides the old indicator is off from the lid





Take the new indicator and install the indicator as the picture(note the direction)



Install the new indicator



Put the indicator in and press by your hand ,done!