
















		Spare part number	Spare part Number (kit)
1	Glass lid assembly	<i>Refer to page 5</i>	
2	Glass lid hinges (pair)	SSPA0010	
3	Pan support (black enamel)	SSPA0952	
	Pan support (cast)	SSPA0951	
4	Pan support clips (x6)	SSPA0800	
	Pan support clips (x50 bulk pack)	SSPA0047	
5	Medium burner assembly (Gloss Cap)	SSPA0110	
	Medium burner assembly (Matt Cap)	SSPA0133	
6	Small burner assembly (Gloss Cap)	SSPA0811	
	Small burner assembly (Matt Cap)	SSPA0109	
7	Hob Thermocouples		
	Front Right	SSPA0688	
	Front Left	SSPA0690	
	Back Right	SSPA0689	
8	Hob spark electrodes (set of 4)	SSPA0327	
9	Lid Bump stops (pair)	SSPA0044	
10A	Burner gas tap	SSPA0433	
10B	Oven gas tap and thermostat	SSPA0447	
10C	Grill gas tap	SSPA0474	
11	Hotplate control switch	SSPA0581	
12	Cooling fan	SSPA0529	
	Fascia	Contact Thetford	
13	Control knobs	<i>Refer to page 3</i>	
14A	Fan thermal switch (horizontal tabs)	SSPA0517	
14B	Fan thermal switch (vertical tabs)	SSPA0513	
15	Thermal switch (grill shut-off – horizontal tabs)	SSPA0518	
16	Spark ignition switch	SSPA0383	
17	Oven lamp switch *if fitted	SSPA0590	
18	Grill door	<i>Refer to page 3</i>	
18A	Grill door bump stops (pair)	SSPA0044	
19	Complete oven door	<i>Refer to pages 4&5</i>	
20	Oven inner glass	SSPA0262	
21	Oven door seal	SSPA0066	
22	Oven shelf	SSPA0980	
23	Grill pan and handle		SSPA2500
	Trivet		
24	Oven burner		SSPA0197
25	Oven spark electrode	SSPA0649	
26	Oven thermocouple		
27	Grill burner		SSPA0178
28	Grill thermocouple	SSPA0650	
29	Grill spark electrode		
30	Spark generator	SSPA0301	
31	Oven lamp (*if fitted)	SSPA0560	
32	Hotplate	SSPA0553	
33	Lid shut-off assembly	SSPA0610	
	Anti-rattle Kit (not illustrated on diagram)	SSPA0085	


Control knobs

Style				
Spare part number	SSPA0900	SSPA0901	SSPA0933	SSPA0932
Colour suffix	Brushed-Nickel/Black (.BNK/BK)	Matt Nickel (.MNK) Brushed Nickel (.BNK) Chrome (.CR) Black (.BK)	Brushed Nickel (.BNK) Chrome (.CR)	Chrome (.CR) Soft Touch Black (.BK)
Set quantity	6	6	6	6
	No cladding		Bottom cladding	
				


Grill Doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO5060.BK01X	Clear	Black	No	N/A		Chrome
SMAO5060.BK02X	Clear	Black	No	N/A		Chrome
SMAO5060.BK03X	Clear	Black	No	N/A		Brushed Nickel
SMAO5060.BK04X	Clear	Black	No	N/A		Brushed Nickel
SMAO5060.BK05X	Clear	Black	No	N/A		Brushed Nickel
SMAO5060.BK06X	Clear	Black	No	N/A		Brushed Nickel
SMAO5060.BK07X	Clear	Black	No	N/A		Chrome
SMAO5060.BK08X	Clear	Black	No	N/A		Chrome
SMAO5060.BK09X	Clear	Black	No	N/A		Black










Drop down oven doors




Left hinged oven doors



Drop down oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO5080.BK01X	Clear	Black	No	N/A		Chrome
SMAO5080.BK02X	Clear	Black	No	N/A		Chrome
SMAO5080.BK03X	Clear	Black	No	N/A		Brushed Nickel
SMAO5080.BK04X	Clear	Black	No	N/A		Brushed Nickel
SMAO5080.BK05X	Clear	Black	No	N/A		Brushed Nickel
SMAO5080.BK06X	Clear	Black	No	N/A		Brushed Nickel
SMAO5080.BK07X	Clear	Black	No	N/A		Chrome
SMAO5080.BK09X	Clear	Black	No	N/A		Black
SMAO5082.BK01X	Clear	Black	Yes	Bottom		Chrome

Left hinged oven doors

Spare part number	Glass	Print	Cladding	Cladding Position	Handle Style	Handle Colour
SMAO5081.BK08X	Clear	Black	No	N/A		Chrome

Glass Lid



Spare part number	Glass	Print	Profile Colour	Protective Strip
SGL2115.BKX	Clear	Black	Black	No
SGL2116.BKX	Smoked	Black	Black	No
SGL2115.BSX	Clear	Black	Stainless	No
SGL2116.BSX	Smoked	Black	Stainless	No
SGL2117.BKX	Clear	Black	Black	No
SGL2118.BKX	Clear	Black	Black	Yes and Frame
SGL2119.BKX	Clear	Black	Black	Yes