

takeyausa.com
Costa Mesa, CA 92626
©2021 All rights reserved

Customer Service
customerservice@takeyausa.com
M-F 8a-4p PST

Follow us
f i t p @takeyausa

96137.12.20

1-YEAR LIMITED WARRANTY

Takeya USA guarantees that the following products: pitcher body, lid, handle, tea infuser and the infuser holder to be free from defects in materials and workmanship. The warranty does not cover damage resulting from misuse.

If you find the product to be defective Takeya USA will replace the damaged item free of charge. You may contact Takeya USA at:



customerservice@takeyausa.com



Mon - Fri 9.00a - 4.00p PST

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Takeya USA guarantees complete satisfaction with the Takeya Flash Chill Iced Tea Maker, or you may return it within 30 days of purchase with proof of purchase for a full refund less shipping fees (if applicable). Contact us at **customerservice@takeyausa.com** or visit **takeyausa.com** for more information.

TERMS & CONDITIONS

The customer must submit a request to Takeya USA Customer Service prior to returning the product. The customer is responsible for return postage (if applicable). Upon receipt of goods in the warehouse, a refund is issued within 7-10 business days.

The following will NOT be accepted for returns:

Products that have been damaged by misuse. Products purchased over 30 days from date of receipt. Any item without a receipt or order#.



ICED TEA LEMONADE

Makes 5 servings

5 tea bags or 5 teaspoons loose leaf black tea

2.75 cups water

7 tablespoons honey

¾ cup fresh lemon juice (approx. 3 lemons)

Ice

ADD TEA: Add tea bags or loose tea into tea infuser. Twist infuser into lid.

BREW: Heat 2.75 cups water to a boil, and pour into Iced Tea Maker (filling it halfway). Lower the tea infuser into the water (allowing steam to vent) and brew for 5 minutes. Lift tea infuser from the brewed tea, place into infuser holder, and twist to detach infuser from lid. Stir in honey until dissolved. Pour in fresh lemon juice.

FLASH CHILL: Fill entire pitcher with ice, seal lid airtight, and shake for 30 second to flash chill. When ready to serve, twist the lid aligning the arrow on the handle with the pour spout for a steady pour.



1QT FLASH CHILL™ ICED TEA MAKER

USER GUIDE



FOR 1QT ICED TEA MAKER

INCLUDED



 BPA free

 Dishwasher safe
(use top rack for lid components)


USE + CARE

Flash Chill Iced Tea Maker
All components are dishwasher safe. We recommend washing all components with soap and warm water before initial use and after every use.

Tea Infuser
Let infuser cool, then dispose of tea leaves in trash. For remaining leaves, turn upside down and tap under running water. For deep cleaning, soak in a 50/50 solution of water and white vinegar, then clean with soap and water.

O-Rings
Check that the o-ring seal is properly placed on the lid and between handle assembly and body to prevent leakage.

Tip
Used tea leaves may be disposed in garden soil, as they make great plant fertilizer!

 Align arrows on lid handle with spout to pour.

 DO NOT fully tighten lid, shake or lay on its side when hot. DO NOT freeze or microwave.

Made in the USA.
Tea infuser/silicone responsibly made in China.

FEATURES



Makes fresh iced tea in minutes



Withstands boiling hot water (212°F) and ice cold temperatures



Stores in fridge door



Twist to pour, align arrows on lid with pour spout



Leakproof, airtight lid, stores upright or on its side



Drinks stay fresh with the airtight lid

HOT BREW + FLASH CHILL METHOD



Add Tea:
Add 5 tea bags or 5 teaspoons* of loose leaf tea into tea infuser. Twist infuser into lid.

* For a stronger flavor add more tea, for a lighter flavor add less tea.



Brew:
Heat 2.75 cups water to the desired hot temperature (depending on the tea type), then pour into Iced Tea Maker (filling it halfway). Lower the tea infuser into the water (allowing steam to vent) and brew for recommended time. Lift tea infuser from the brewed tea, place into infuser holder, and twist to detach infuser from lid. Stir in sweetener if desired.



Flash Chill:
Fill entire pitcher with ice, seal lid airtight, and shake for 30 second to flash chill. When ready to serve, twist the lid aligning the arrow on the handle with the pour spout for a steady pour.

COLD BREW METHOD



Add Tea:
Add 5 tea bags or 5 teaspoons* of loose leaf tea into tea infuser. Twist infuser into lid.

* For a stronger flavor add more tea, for a lighter flavor add less tea.



Cold Brew:
Fill Iced Tea Maker ¾ of the way full with cold, filtered water. Lower tea infuser into water, seal lid airtight and brew in the refrigerator for 4 - 12 hours (depending on the tea type).



Serve & Store:
When brewing is complete, lift tea infuser from the brewed tea, place into infuser holder, twist to detach from lid. Serve or seal lid airtight and store in the refrigerator. When ready to serve, twist the lid aligning the arrow on the handle with the pour spout for a steady pour.