

Inkjet Fire Retardant Fabric

Non-washable fabric for inkjet printers

Print directly onto these 100% polyester, fire retardant fabric sheets using a top-loading inkjet printer. These white, translucent sheets are perfect for making lampshades or covers for candle holders but they are fire retardant not fireproof; do not expose the fabric to naked flame.

They are so simple to use; print onto them as if printing normal paper. The fabric will not fray when cut, is water-resistant and safe for exposure to temperatures up to 220°C.

Instructions

Step 1 - Choose your design and resize it to fit your fabric sheet.

Step 2 - Place the fabric sheet into your printer feed tray. Make sure it is straight and that you will be printing onto the

whiter, treated side of the fabric. Print using your default print settings, making sure you select the correct paper size. The fire-retardant fabric does not have a backing sheet and can therefore be 'relaxed' in top-loading printers so you may need to move the edge of the fabric up to the printer's roller feeds to get it started. If the fabric catches on the side of the printer whilst printing you can use your finger to gently encourage it back into the correct feed position.

Step 3 - Allow your printed fabric to dry fully before using it.

Washing Information

These fabric sheets are water-resistant and can be wiped clean, but they are not washable.