

Inkjet Silk

Washable fabric for inkjet printers

Print directly onto these sheets of 16mm Habotai silk using a top-loading inkjet printer. The fabric sheets have a paper backing to help them feed through your printer smoothly.

They are so simple to use; print onto them as if printing normal paper, then peel off the backing paper and your completely unique and personalised fabric sheet is ready to use.

Instructions

Do not attempt to remove or reposition the backing paper prior to printing.

Step 1 - Choose your design and resize it to fit your fabric sheet.

Step 2 - Press the silk fabric using a dry iron set to the low/silk/nylon setting to ensure that it is firmly attached to its backing paper and will run through the printer smoothly.

Step 3 - Place the fabric sheet into your printer feed tray. Make sure it is straight and that you will be printing onto the fabric side of the sheet. Print using your default print settings, making sure you select the correct paper size. If the fabric catches on the side of the printer whilst printing you can use your finger to gently encourage it back into the correct feed position.

Step 4 - Leave the fabric to dry before carefully peeling off the backing paper. Your fabric is now ready to use. If you intend to sew your fabric we recommend pre-washing by hand and ironing on a low/silk/nylon setting to ensure that colours do not run when the finished piece is washed.

Washing instructions

These fabric sheets have been pre-treated with a non-toxic chemical to help fix ink from inkjet printers. They can be hand washed as you would wash any silk fabric; in cool water with a very mild fabric detergent. These silk sheets can also be dry cleaned.