


RSNAV ANDROID SYSTEM BASIC DIAGRAM



* TF CARD SLOT IS LOCATED IN THE BACK SIDE OF THE DEVICES IN SOME MODELS.

* IN SOME MODELS, MIC MAY BE EXTERNAL.



Only for RHD and A3, Q3 model