



SHATTERIZER™



dabtabs™

# User Manual



*To load, gently twist  
and pull off glass top!*

## Dabbing Reinvented

1. Place the DabTab so it lays flat at the bottom of the ceramic DabTabs coil.
2. Click button twice for pre-heat feature, watch for DabTab to release vapor.
3. Vape! Draw as you would normally, until vapor stops producing and DabTab color darkens.
4. Enjoy! Remove DabTab using tweezers when hot and let cool before disposing.

**CAUTION DabTabs get very hot.**

Vaporizer may be hot after use. Not intended for consecutive uses, please let cool between sessions. Ensure silicon sleeve is in place, do not operate without glass top. Always use tweezers included with DabTabs (sold separately) to remove DabTab.

**PLEASE:** Do not touch, remove or clean coil until completely cooled, may be hot after use. Do not travel with the DabTab on coil, in vaporizer, may be hot after use. Do not use if unusually hot to touch.

**Please ensure battery is off when not in use!**

**THANK YOU - Visit [DabTabs.com](http://DabTabs.com) for more info!**



## Portable Vaporizer Pen

- Click the silver button 5 times rapidly, within two seconds, to turn ON and OFF.
- Base light and button glow red while charging and will stop when fully charged.
- Flashing light will occur to alert if atomizer is not screwed in correctly, battery is drained or coil is burnt out.
- For 15 second pre-heat feature click button twice, base light and button will glow orange while heating.
- To vary temperature, click silver button 3 times quickly:
  - Low Temp** = Red: 20 Watt - 3.4 V
  - Medium Temp** = Blue: 25 Watt - 3.8 V
  - High Temp** = Orange: 30 Watt - 4.2 V
- Light will flash 8 times at 15 second continuous heat cut off point.

**THANK YOU** - Visit [Shatterizer.com](http://Shatterizer.com) for more info!  
DabTabs extract delivery system sold separately.

[DabTabs@shatterizer.com](mailto:DabTabs@shatterizer.com)





SHATTERIZER™



# Portable Vaporizer Pen

## CLICK, BLINK & LIGHT GUIDE

---

### Click Guide

5 Clicks On

5 Clicks Off

2 Clicks Pre-Heat Function On

1 Click Pre-Heat Function Off

3 Clicks Variable Voltage temperature change

---

### Blink Guide

3 Blinks - Variable Voltage change confirmation

3 Blinks - Unscrewed Coil, Base, Atomizer Alert

5 Blinks - Change Coil

8 Blinks - Auto Shut Off for 15 second heat option

10 Blinks - Charge Battery

---

### Light Guide

Red light On when plugged in and recharging

Red light Off when fully charged

Variable Voltage Settings

Orange - HIGH - 30 Watt - 4.2 V

Blue - MEDIUM - 25 Watt - 3.8 V

Red - LOW - 20 Watt - 3.4 V

---

Flickering Light - Breathing Light - IN USE

[DabTabs@shatterizer.com](mailto:DabTabs@shatterizer.com)

