

User's Manual

Pasadena 94'



FUTLOV®

a brand with a **purpose**

TABLE OF CONTENTS

Introduction to FUTLOV WATCHES	Page 1
Introduction to your Pasadena 94'	Page 3
Display and buttons	Page 4
Setting the time	Page 4
Setting the date	Page 5
Using the chronograph	Page 5
Chronograph reset	Page 6
Care instructions	Page 7



The first

Soccer inspired watch

With a social purpose

Our watches, with modern style in mind, are beautifully designed with soft and subtle soccer details on them.

They are crafted with premium and good looking materials, being unisex and casual, they fit and occasion, wear it in any sport activity or professional meeting. Our watches measure and resist time

Purpose

An article of soccer gear will be donated to kids in need around the world for every watch purchased. 1to1GIVING.

We are actively looking for charities and non-profits who can participate in our "1to1GIVING back program".



Pasadena 94'

Introduction to parts & features



Case size

42 mm case thickness 12mm



Case

316L brushed pvd coated stainless steel



Glass

Scratch resistant sapphire crystal



Strap

Soccer pattern 100% genuine leather



Strap width

22 mm



Movement

Japanese Miyota 6S21
Chronograph



Dial

Gun metal hands and markers
Details: Color chronograph second
hand / date window / luminosity hands



Subdials

Chronograph hour timer /
second hands




Water resistant

3 Atm water proof



DISPLAY AND BUTTONS




SETTING THE TIME

1. Pull the crown out to the 2nd Click Position.
2. Turn the crown clockwise to set hour and minute hands.
3. After the time has been set, push the crown back to the Normal position.



SETTING THE DATE

1. Pull the crown out to the 1st Click Position.
2. Turn the crown clockwise to set the date.
 - * If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change on the following day.
3. After the date has been set, push the crown back to the Normal position.




USING THE CHRONOGRAPH

This chronograph is able to measure and display time in 1/4 second united up to maximum of 59min 59sec.

[Measuring time with the stopwatch]

1. Press button "A" to start the chronograph.
2. The chronograph can be started and stopped each time button "A" is pressed.
3. Press button "B" to reset the chronograph and chronograph minute and second hands return to their Zero positions





CHRONOGRAPH RESET (INCL. AFTER REPLACING BATTERY)

This procedure should be performed when the chronograph second hand does not return to the Zero position.

1. Pull the crown out to the 2nd Click Position.
2. Press the button "A" once to set the chronograph second hand to the Zero position.
* The chronograph hand can be advanced rapidly by continuously pressing button "A".
3. Once the hands are set at Zero position, reset the time and return the crown to its normal position.

CARE INSTRUCTIONS

➤ **Cleaning**

Clean your watch regularly as follows; this will maintain its aesthetic appeal and ensure it stays in good working order.

- Ensure that the crown is completely screwed down before you get started.
- Avoid contact with detergents, solvents, cosmetics or any other chemical product, as these may damage the water-resistant gaskets and the bracelet.
- If you have any doubts whatsoever about the water resistance of your watch, simply clean it with a soft brush, and then dry it.

➤ **CONDENSATION**

A small amount of condensation may form under the crystal of your watch if there is a sudden temperature change. This mist will disappear by itself and will not impact the watch function. If the condensation persists, please contact FUTLOV watches.

➤ **CRYSTALS**

The crystal in your watch may be coated with an anti-reflective treatment (single or double), to make the time more readable. Marks may appear due to normal wear and tear of the watch, and are not covered by the Warranty. The coating will be sufficient if you use your watch normally.

➤ **WATER RESISTANCE**

Given the nature of rubber seals, water resistance cannot be a permanent condition. The rubber seals are designed to prevent water entry, however the fact that they are under constant pressure means that over time they will deteriorate.

➤ **LEATHER STRAP**

Be sure to avoid letting the watch get into contact with water. Please note that no matter how careful you are with leather, it is a living material and its colour will naturally (slightly) fade or darken over time. Leather straps should be cleaned with a dry, soft cotton cloth. Avoid any abrasive products during cleaning