
business Epleasure co.



CONTENTS


1. CABANA CANOPY

2. LOWER POLE

3. GUIDE POLE

4. STAKES

5. CARRY BAG



SIMPLE SET UP

IN THE SAND OR SOFT GROUND

Check USEFUL INFO box on next page for set up on hard ground & grass




1. SECURE GUIDE PIPE. Dig hole around 6" deep & Insert ground screw. Twist it into firm sand until depth sticker is just below ground level & pack sand tightly around screw and pole.




2. INSERT LOWER WOOD POLE inside the guide pipe.

NOTE: This does not have to be very sturdy -Simply just enough to help stand the cabana up while you fill the leg bags with sand



3. OPEN CANOPY.


Holding the cabana upside down, check all legs are separated with no tangles or twists. Give it a little shake if needed as you push the slider up and raise cabana up-right. Ensure the pole runner clicks in firmly.





Once upright, check all the legs are hanging down correctly.

IMPORTANT: All 4 legs should be just touching the ground. If the legs are higher off the ground, screw the cabana further into the sand by twisting the guide pipe.



5. FILL LEG BAGS

Once legs are touching the ground fill each leg with sand. Start by adding a few handfuls in each side, then go around and fill each leg bag and adjust legs so they are straight.

TIP: If windy, add more/compact sand on the side it's blowing from.

USEFUL INFO.

Did you know the cabana can stand up WITHOUT the guide pipe!
This is great news if you wish to **set it up at the park or by the pool** for example.

Your cabana comes with 4 stakes so you can pin the legs directly to the ground (ideal for grass areas!) or, if on a hard surface, simply replace the sand/stakes with any suitable weights like, pebbles or stones of even water bottles. NOTE: Hammer not provided.

NOTE!

DO NOT OVER FILL THE BAGS WITH ANYTHING HIGHER THAN THE POCKETS.

ADDED DOWN FORCE ON THE LEGS CAN CAUSE DAMAGE.

PACK DOWN



1. EMPTY SAND POCKETS

Keep Cabana in its pole and empty all sand from all sandbags.



3. HANG SAND POCKETS ON TOP

Hook the 4 sand pockets on the top of the umbrella.


NOTE: If you cannot reach. Remove the upper part of the cabana and do this step on the ground.



2. COLLAPSE CANOPY

Standing under the cabana, push in the wire button and collapse the canopy.

NOTE: do it faster to puff the canopy out and make it easier to pack.



4. SEPARATE POLES & PACK

Simply separate the upper from lower pole and place into bag along with all poles and accessories.

NOTE: To help fit the cabana back in the bag, twist the fabric around to more compact.

IMPORTANT INFORMATION!

Please read the following before use of your B&PCo Cabana.

Although providing shade from the direct sun, reflections from sand and water can still expose you to harmful UV rays!

It is advised that you also use sunscreen, hat and glasses when outside - especially around white sand or water!

Set up and use of a Business & Pleasure Co product must follow the "Set Up" instruction guide

Business & Pleasure Co. are not responsible for the miss use or poorly set up products that lead to damage or harm to any persons or property.

For all warranty information, please visit www.businessandpleasureco.com

CARE INSTRUCTIONS.

- 1. Always use your cabana as per the set up instructions.
- 2. To maintain and extend the life of your product keep it dry and clean of any salt, sand or chlorine or chemical residue, keep it in its carry bag when in transit or storage.
- 3. If your cabana gets wet, dry with soft towel and allow fringe to drip dry in the shade before packing way.
 - 4. Reduce unnecessary and excessive exposure to direct sunlight by putting away when not in use.
- 5. Maintain the function of your connection by regular use and service. Service your connection be regular cleaning and ensuring salt and sand particles are removed before storage. In some cases a greasing agent (like WD40) is recommended if storing for extended periods of time.

Note: Avoid getting greasing agent on fringe of canopy.

FEATURES



VERSATILE

LARGE AND STYLISH, THE CABANA CAN BE SET UP ALMOST ANYWHERE. BEACH, PARK OR POOLSIDE.



EXTRA SECURE

LARGE GROUND SCREW FOR FIXING POLE AIR VENT & SAND BAGS IN EACH LEG.



PREMIUM CANVAS

UV, WATER & MOLD TREATED CANVAS

COTTON BUILLION FRINGE

DIMFNSIONS

SIZE WHEN SET UP: 6.5' x 6.5' Wide x 7.8' High / 2m x 2m x 2.4m h SIZE IN CARRY BAG: 3.5' / 1.1m Long

GOT QUESTIONS?

Email orders@businessandpleasureco.com Or vist www.businessandpleasureco.com