
THE PREMIUM & HOLIDAY

USER GUIDE


BEACH UMBRELLA

business Epleasure



CONTENTS

1. UMBRELLA 2. CARRY BAG



SIMPLE SET UP IN THE SAND OR SOFT GROUND

1. DIG HOLEDig a small hole in sand

2. LOOSEN HINGE SLIGHTLY Twist hinge to the left to loosen

3. STRAIGHTEN POLE Ensure hinge is tight



4. UNDO STRAPUndo strap and give the umbrella a shake

5. OPEN UMBRELLATurn the umbrella the right way up and push slider to the top

6. TWIST INTO HOLEPut pole in the hole and spin until head is buried. Fill and pack down with sand

FOR WINDY DAYS






1. FILL BOTTOM OF BAG. (Note Premium Umbrella has Dedicated Sand Pocket) Add sand to the bottiom of bag or pocket to desired weight.


2. CLIP TO UMBRELLAClip umbrella bag to the umbrella Ribs or pole spring.

3. OR WRAP AROUND POLEWrap strap around the pole



FOR PATIO USE





1. TEMPORARY PATIO

Use with a stand, table or lean against a wall for temporary patio shade.

TIP: To use on flat ground lay the lower pole on the ground and tilt the hinge like this:
Then use the carry bag to anchor

2. PROTECTIVE COVER

When not in use, collapse the canopy and slide the carry case over your umbrella. This will help to prevent fading and possible fabric damage.

IMPORTANT: This is a portable beach umbrella and is not designed to be up or out permanently. For more permanent home and patio options please check our website.



PACK DOWN



1. REMOVE FROM HOLE Remove umbrella

2. GIVE IT A SHAKE

Give the umbrella a shake to remove any excess sand, then do up the strap



3. TILT HINGE

Loosen hinge and fold lower pole towards the umbrella. Then tighten again.



4. RETURN TO BAG

Give your umbrella a final wipe down and return to carry bag

IMPORTANT INFORMATION!

Please read the following before use of your B&PCo Umbrella.

Although providing shade from the direct sun, reflections from sand and water can still expose you to harmful UV rays!

It is advised that you also use sunscreen, hat and glasses when outside - especially around white sand or water!

Set up and use of a Business & Pleasure Co product must follow the "Set Up" instruction guide in this booklet

Business & Pleasure Co. are not responsible for the misuse or poorly set up products that lead to damage or harm to any persons or property.

For all warranty information, please visit www.businessandpleasureco.com

CARE

- 1. Always use your umbrella as per the set up instructions
- **2.** To maintain and extend the life of your product keep it dry and clean of any salt, sand or chlorine or chemical residue, keep it in its carry bag when in transit or storage.
- **3.** If your umbrella gets wet, dry with soft towel and allow fringe to drip dry in the shade before packing way.
- **4.** Reduce excessive exposure to direct sunlight by putting in bag when not in use.
- **5.** Maintain the function of your hinge by regular use and service. Service your hinge by regular cleaning and ensuring salt and sand particles are removed before storage. In some cases a greasing agent (like WD40) is recommended if storing for extended periods of time.

Note: Avoid getting greasing agent on fringe of canopy.

FEATURES

OUR MOST POPULAR BEACH UMBRELLAS ARE PORTABLE TO CARRY AND EASY TO SET UP. COMPARE STYLES BELOW.

	Premium	Holiday
PRIMARY USE	Beach and temporary outdoor patio	Beach
SPAN x HEIGHT	6' W x 7.5' H 180 x 230cm	5' W x 6.5' H 150 x 200 cm
WEIGHT	8lbs / 4 kg	4lbs / 2 kg
SET UP	1-2 Minute	1-2 Minute
UV BLOCKOUT	50+ / 98%	50+ / 98%
CARRY BAG	Yes	Yes
MATERIAL	10 oz Canvas UV & Water Resistant	8 oz Canvas
POLE	11/8" / 29mm Eco Timber	0.8 & 1" / 23 & 25mm Eco Timber
FITTINGS	Marine Grade Aluminium & Nylon	Nylon/Aluminium
FRINGE	Cotton	Polyester

GOT QUESTIONS?

Email orders@businessandpleasureco.com Or vist www.businessandpleasureco.com