049-239 AtLite®

Installation Instructions for the AUX Universal Edge Lit Exit Lens

WARNING

WARNING

Risk of Fire/Electric Shock

If not qualified, consult an electrician.

Risk of Electric Shock

Disconnect power at fuse or circuit breaker before installing or servicing.

Important Safeguards

WHEN USING ELECTRICAL EQUIPMENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE OBSERVED INCLUDING THE FOLLOWING.

- 1. READ AND FOLLOW ALL SAFETY INSTRUCTIONS
- 2. Dry location only. Do not use outdoors.
- 3. Do not use in hazardous locations, or near gas or electric heaters.
- 4. Do not let power supply cords touch hot surfaces.
- 5. Do not use this equipment for other than the intended use.
- 6. Installation is to be performed only by qualified personnel.
- 7. Install in accordance with National Electric Code and local regulatory agency requirements.
- 8. The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- 9. Equipment should be mounted in locations and at heights where it will not readily be subjected to tampering by unauthorized personnel.
- 10. SAVETHESE INSTRUCTIONS

Installation

- 1. Install electronics housing as described in the instructions included in the fixture.
- 2. Determine the configuration of the lens: single sided or double sided; chevrons required or not required; and mirror background, white background, or clear.

The lens is packaged in a single sided configuration with a clear background.

NOTE: If using the lens with the default transparent background (instead of the provided white or mirror backgrounds) it must be installed only where there is adequate color contrast between the sign legend and the interior wall finish behind the sign, to provide for sufficient visibility. If a change to double sided, or a different background, is desired, then the lenses must be separated by peeling off the clip on lens reflector (See Figure 1). Otherwise, proceed to Step 6.

- 3. After removing the clip on lens reflector, the number of sides and background can be configured as desired. (See Figure 2)
- 4. Re-attach the clip on lens reflector.
- 5. If chevrons are desired, lay the cardboard chevron guide on the lens, aligning the folds along the bottom and sides of the lens. (See Figure 3) Otherwise, proceed to step 9.






FIGURE 1




Installation Instructions for the AUX Universal Edge Lit Exit Lens

- 6. Apply the stick on chevrons through the windows in the chevron guide as desired. Remove bubbles in the sticker by rubbing them out with the back of your thumbnail.
- 7. Repeat on the back of the lens as needed.
- 8. Insert the lens into the housing until both snaps engage. (See Figure 4)
- 9. Illuminate the sign as described in the housing instructions.








DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY

The information, recommendations, descriptions and safety notations in this document are based on Cooper Lighting Solutions' experience and judgment and may not cover all contingencies. If further information is required, an Cooper Lighting Solutions sales office should be consulted. Sale of the product shown in this literature is subject to the terms and conditions outlined in appropriate Cooper Lighting Solutions selling policies or other contractual agreement between Cooper Lighting Solutions and the purchaser.

THERE ARE NO UNDERSTANDINGS, AGREEMENTS, WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OTHER THAN THOSE SPECIFICALLY SET OUT IN ANY EXISTING CONTRACT BETWEEN THE PARTIES. ANY SUCH CONTRACT STATES THE ENTIRE OBLIGATION OF COOPER LIGHTING SOLUTIONS. THE CONTENTS OF THIS DOCUMENT SHALL NOT BECOME PART OF OR MODIFY ANY CONTRACT BETWEEN THE PARTIES.

In no event will Cooper Lighting Solutions be responsible to the purchaser or user in contract, in tort (including negligence), strict liability or other-wise for any special, indirect, incidental or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recom-mendations and descriptions contained herein. The information contained in this manual is subject to change without notice.



1121 Highway 74 South Peachtree City, GA 30269 P:770-486-4800 www.cooperlighting.com

© 2020 Cooper Lighting Solutions All Rights Reserved Printed in USA Publication No. ADA140170

