

# Instruction Sheet For VT2 Series

## NOTES:

### 1. CONNECTOR PLUGS MUST BE INSTALLED

