




Installation Instructions	Product : 1710LED & 1720LED
Effective Date: March 25, 2019	Part Description: Villa Post Top Fixture


	WARNING: To avoid fire, shock or death, turn off and lockout power before performing any maintenance.
	CAUTION: This Fixture must be wired in accordance with the National Electric Code (NEC) and all applicable local codes. Proper grounding is required. A qualified electrician must do all work.



Step 1: Disconnect the male quick disconnect from the female quick disconnect.

Step 2: Wire the free end of the male connector to the supply lines from pole. See wiring schematic below.

Step 3: Connect the male and female connectors together and press firmly together to lock them.




Step 4: Guide wires into the tenon and carefully install the fixture on top of the tenon. Do not pinch wires.

Step 5: Level fixture and ensure that the Street Side Label is facing the street



Step 6: Uniformly tighten all 3 set screws located at the bottom of the fixture to secure the fixture to the Tenon.



Revision History				
Rev	Description of Revision	Release Date	Design Engineer Author	Manufacturing Engineer Approval
A	Create Fixture Installation Instructions	03/27/2019	Mohan Rao	Grant Burton