FLIGHT ARMS

INSTALLATION INSTRUCTIONS

WARNING: TO AVOID FIRE, SHOCK OR DEATH, TURN OFF AND LOCKOUT POWER BEFORE PERFORMING ANY MAINTENANCE.

CAUTION:

THIS FIXTURE MUST BE WIRED IN ACCORDANCE WITH THE NATIONAL ELECTRIC CODE AND ALL APPLICABLE LOCAL CODES, PROPER GROUNDING IS REQUIRED. ALL WORK SHOULD BE DONE BY A QUALIFIED ELECTRICIAN.





800-621-3376 555 Lawrence Ave., Roselle, IL 60172 info@sternberglighting.com www.sternberglighting.com

7/16 STERNBERG LIGHTING. ALL RIGHTS RESERVED. PRINTED IN THE USA.

FLIGHT ARMS - PAGE 2

INSTALLATION INSTRUCTIONS

WARNING: TO AVOID FIRE, SHOCK OR DEATH, TURN OFF AND LOCKOUT POWER BEFORE PERFORMING ANY MAINTENANCE.

CAUTION: THIS FIXTURE MUST BE WIRED IN ACCORDANCE WITH THE NATIONAL ELECTRIC CODE AND ALL APPLICABLE LOCAL CODES, PROPER GROUNDING IS REQUIRED. ALL WORK SHOULD BE DONE BY A QUALIFIED ELECTRICIAN.



STEP 6

Secure arm onto pole assembly with the two screws and washers provided. Connect supply wires down the base. Complete the installation of fixture.





800-621-3376 555 Lawrence Ave., Roselle, IL 60172 info@sternberglighting.com www.sternberglighting.com

7/16 STERNBERG LIGHTING. ALL RIGHTS RESERVED. PRINTED IN THE USA.