INSTALLATION INSTRUCTIONS

READ IMPORTANT SAFETY TIPS BEFORE PROCEEDING WITH INSTALLATION




Turn fixture off! (Place wall switch in off position, if fixture has built-in switch or chain pull, switch or pull chain so fixture is off.)




Next - go to the main fuse box. If your fuse box has an ON/OFF switch, simply place main power switch in OFF position.



Screw-in type fuses - unscrew the fuse or fuses that control the power to the fixture or room you are working in.



ATTACH CROSS BAR to outlet box with outlet box screws (not provided). THREAD NIPPLE into the cross bar. Adjust nipple to proper height for mounting fixture.




wire connectors (not provided)


CONNECT FIXTURE WIRES TO SUPPLY WIRES.

- -Take the black fixture wire(s) and place evenly against the black wire from outlet box. Do not twist the wires together before using a wire connector.
- -Fit a wire connector over wires and thread the connector clockwise until you feel a firm resistance.
- -Gently try to remove wires from connector, if you can, re-thread wire connector.
- -Repeat process for connection of white fixture wire(s) to white wire from outlet.
- -Attach ground wire(s) as shown.






fixture mounting knob.



POSITION THE FIXTURE BASE over the INSTALL LENSES into cage. Place flat nipple and secure into place with the lens in bottom and insert four side lenses as shown.



ALIGN AND INSERT round ended pins on bottom of self ballasted lamp into circular opening in lampholder key hole slots. Grasp base and rotate clockwise. Use MAX wattage GU24 base, self ballasted compact lamp specified on fixture. Align holes in cage with holes in base and secure with fixture mounting screws provided.

If lamp is marked

BALLAST AND LAMP REPLACEMENT INSTRUCTIONS

Product contains an integrated Lamp/Ballast combination. To remove, grasp plastic area on each side of bulb area and rotate counterclockwise. Replace with MAX SBCFL(GU-24) that is specified on the fixture and marked with the UL and C, US Logo. Use SBCFL marked - Not for use where directly exposed to water. Do not use SBCFL marked - Not for use in totally enclosed luminaire.

COLD WEATHER STARTING INFORMATION: For temperatures below 0°F, leave the lamp on continuously - starting with warm lamps. NOTE: If lamp starting becomes a problem in any cold weather application, remove the lamp form the fixture - bring the lamp indoors so that it becomes warm - then reinstall the lamp into the fixture and leave the fixture on continuously. Do not place lamp in an oven, microwave or similar heat producing devices.



disposal laws. See www.lamprecycle.org Clean only with mild soap and

contains mercury. Follow applicable

water. Avoid spraying with cleaners. insecticides, and pesticides that are petroleum based hydrocarbon products.

These will degrade luminaire.

IS047GU Rev B