

AirInjector Controller

Controls a dump valve to inject air into the milkline for more effective washing. In addition an air purge system can be controlled to evacuate fluid in the milkline at appropriate times.



-
- Inject start on power up or external input.
 - Inbuilt air purge control.
 - Air purge controlled automatically or by external input.
 - Adjustable inject time (1s to 7s).
 - Adjustable delay time (5s to 50s).
 - Adjustable air purge time (30s to 120s).
 - Multi-colour front panel LEDs show inject, delay and purge status.
 - Requires external 12V or 24VDC power supply.

innovAg

InnovAg Pty Ltd

37/328 Reserve Rd, Cheltenham Victoria 3192, Australia
sales@innovag.com +61 3 9583 2832

