

Soft Egg Crates® and Stretch Frames® for Octa Softboxes



Attaching Soft Egg Crates® to Octa Softboxes

- Locate the double stitched or color-coded corner seams and place two corners of the Soft Egg Crate between the corners of the softbox.
- Press the hook and loop fastener together, using thumb and forefinger.
- Repeat the same procedure on opposite sides, then on the remaining sides of the box.

Remove and Store Soft Egg Crates®

- Release the Soft Egg Crate, then on a flat surface, gather the sides until the Soft Egg Crate forms a circular shape.
- Return to zippered case.



Lighttools® Stretch Frames®

Stretch Frames eliminate sag - to give you complete control - regardless of how much your lightbank is angled downward.

Essential for larger softboxes, Stretch Frames are a **one-piece, collapsible "frame"**. When inserted into the softbox the Stretch Frame creates rigid sides to keep the Lighttools Soft Egg Crate taut for 100% efficiency.

Not required for ez[POP] models with builtin tensioning.

Installing Stretch Frames®

Shake the Stretch Frame to allow the bungee cord to pull the joints together.

Ensure the diffuser is placed on the innermost edge of the recessed hood to allow ample surface area for the Lighttools Stretch Frame and Soft Egg Crate.

Place the Stretch Frame assembly into the recess of the softbox, directly in front of the diffuser. Then install the Soft Egg Crate as described above.

One Stretch Frame can be used for all Lighttools Soft Egg Crates of the same outside dimensions, regardless of their cell size.

