




Included




For fuse values:  
refer to the user manual


Fuse (not included)



Not included



Battery





Battery Cable +




Battery Cable -




Remote control




UTP-Cable




V-sense



AC-OUT



AC-IN



Current Transformer