




HOW TO CHANGE THE DISPLAY MODE




HOW TO DISPLAY CALENDAR




HOW TO SET NORMAL TIME




HOW TO SET NORMAL TIME




HOW TO SET ALARM TIME




HOW TO SET ALARM TIME




How to set the alarm, ringing on the hour and key tone




How to set the alarm, ringing on the hour and key tone




HOW TO USE THE CHRONOGRAPH




HOW TO USE THE CHRONOGRAPH




HOW TO USE TIMER




HOW TO USE TIMER



HOW TO SET SECOND TIME ZONE



HOW TO USE EL LIGHT



CARE OF YOUR WATCH

1. This watch contains precise electronic components. Never attempt to open the case or remove the back cover.
2. Do not operate buttons while underwater, or while swimming or diving.
3. Should water or condensation appear in the watch, immediately have the watch checked. Water can corrode electronic parts inside the case.
4. Avoid severe impact: The watch is designed to withstand impact under normal use. Do not subject it to severe impacts or rough usage, and do not drop it onto hard surfaces.
5. Avoid exposing the watch to temperature extremes.
6. Clean the watch with a soft cloth and clean water only. Avoid using chemicals, especially soap.
7. Keep your watch away from strong electric fields and static electricity.

FEATURES AND SPECIFICATIONS

1. Standard display mode: Hour, Minutes, Seconds, Month, Day of the week.
2. Function:
  - \* Month, Date AM/PM and Electro-Luminescent light.
  - \* Alarm function with buzzer signal output.
  - \* Chronograph function with lap operation.
  - \* Hourly chime.
  - \* 12/24 hour format switch option.
  - \* Timer.
  - \* Second time zone.
3. Accuracy at normal temperature (25°C): ± 30 seconds a month.
4. Normal operating temperature range: 10°C ~ 40°C.

GUARANTEE CERTIFICATE  
CERTIFICAT DE GARANTIE

MODEL:  
MODELE: \_\_\_\_\_

DATE OF PURCHASE:  
DATE D'ACHAT: \_\_\_\_\_

OFFICE DEALER STAMP:  
TAMPON DU DETAILLANT OFFICIEL:

