

BULLPUP

TIME TO HAVE A LITTLE FUN >>



BULLPUP ASSEMBLY GUIDE



PARTS LIST

- A. Left housing body
- B. Right housing body
- C. Picatinny rail
- D. Barrel grip
- E. Stock
- F. Charging handle
- G. Magazine
- H. Non-firing rounds
- I. Display stand

HARDWARE LIST

- [3] Screws
- [1] Sling ring
- [1] Screwdriver with magnet

1



Place picatinny rail (C) onto left housing body (A).

2



Insert charging handle (F) into left housing body (A) and slide forward.

3



Insert barrel grip (D) into holes at bottom of housing body (A).

4



Place sling ring into provided hole. Snap right housing body (B) into place.

5



Insert screws into the 3 holes on the right side of housing body (B).

6



Push together stock (E) and housing body.

7



Load non-firing rounds (H) into magazine (G). Slide magazine until it clicks into place, and show off your GoatGun on the display stand (I).



GOATGUNS™
GREATEST OF ALL TIME | TOY MODELS

Facebook icon GOATGUNS Instagram icon @GOAT.GUNS Website icon GOATGUNS.COM



LEGAL DISCLAIMER: GOATGUNS ARE MANUFACTURED AS NON-FIRING MODELS. ANY MODIFICATIONS OR REVERSALS DONE MAY BE SUBJECT TO LEGAL ACTION.

SCAN FOR HOW TO VIDEO