



Outdoor Timber Care Kit

www.pedersenlennard.co.za

Pedersen + Lennard furniture has been designed and crafted to last for generations. To ensure the longevity of your solid wood furniture, it is essential that it is cared for correctly.

Please take note of our care instructions and action accordingly, as failure to do so may void warranty. If unsure, please contact us and we'll gladly assist.

HOW TO OIL YOUR WOOD FURNITURE:

The Linseed Oil provided is ready to use, please do not dilute.

FOLLOW THESE QUICK EASY STEPS:

- 1. Sand timber**
Lightly sand the wood with 220 grit sand paper until smooth to touch.
- 2. Apply Linseed Oil**
Apply a single coat with a mutton cloth or clean white cloth. Avoid dripping or pooling on the surface.
- 3. Allow 6hrs to cure**

Congratulations, you're done!

We trust this information is satisfactory. Should you need further information please do not hesitate to contact us.

admin@pedersenlennard.co.za | www.pronature.co.za

HOW TO CARE FOR YOUR WOOD FURNITURE:

- When using the furniture for serving food and drinks, protective mats and coasters are recommended.
- Dust lightly with a clean, dry cloth.
- Wipe up spillages as soon as possible with a diluted solution of your Pronature Plant Soap Concentrate or a clean damp cloth.
- We do not recommend using any chemical and household cleaners as these can strip the wood of its natural oils and moisture leaving it unprotected.

HOW OFTEN TO RE-OIL YOUR WOOD FURNITURE:

We recommend re-oiling your purchase:

- 1st Re-Oiling | Two months after delivery.
- 2nd Re-Oiling | Every 6 months or when the wood looks dull, dry or rough.

IROKO WOOD:

We use Iroko as our preferred outdoor choice of timber as it is naturally durable, and has rot and insect resistant properties.

It is an African hardwood that is a yellow/medium brown and ages into a beautiful and timeless silver-grey patina.

Kindly note: Fine hairline cracks may likely develop overtime. This is normal and is part of the natural aging process of the wood when exposed to the elements.

CAUTION:

Linseed oil is ignitable! Soaked, used cloths may spontaneously combust, and should be spread open or kept safely in a tightly sealed container or alternatively, submerge in water after use.

Ingredients:

100% Boiled Linseed Oil
ProNature Plant Soap: Water, Potassium Soaps, Citrates, Ethanol, Essential oils

Cleaning:

Use ProNature Plant Soap for all wooden surfaces.

Storage / Shelf Life:

Store in a cool, dry place. Minimum stability of 12 months in a closed container.

Disposal:

Oil based products must be taken to a hazardous landfill site or other municipal collection points.
DO NOT empty this oil based liquid residue into drains.

Safety:

Natural ingredients may cause allergies. Use only as directed. Keep out of reach of children.

General:

The above information given is intended as a guideline only, as this product is used outside of our control.
ProNature and Pedersen + Lennard cannot be held liable for any loss or damage whatsoever relating to the application or surface it is applied to.
We reserve the right to change specifications at any time and without prior notice.

The products included in your timber care kit are available for purchase from www.pronature.co.za and most hardware stores.

Good design and quality craftsmanship

Made in Cape Town, South africa

www.pedersenlennard.co.za