



how to use T-122

3 IN 1 MULTI-FUNCTION
TEA PROCESSOR

T-122 is the most famous machine that used by most of bubble tea chainstores in Taiwan and Asia countries

The functions, features, quality of the spare parts bring trust that T-122 is the most reliable product for the business



how to use T-122

3 IN 1 MULTI-FUNCTION
TEA PROCESSOR



Identification of parts



How to operate



Safety Instructions



Troubleshooting


condiment lid



jar cover



stainless steel jar
800cc



outer gasket



tea extractor
filter



filter gasket



extractor blade




waterproof gasket



jar base




T-122
main machine




condiment lid



jar cover



stainless steel jar
800cc



outer gasket



filter



filter gasket



shaker blade set



waterproof gasket




jar base




condiment lid



jar cover



stainless steel jar
800cc



outer gasket



filter



filter gasket



milk froth blade set



waterproof gasket



jar base



tea
extractor
T-122

3 IN 1 MULTI-FUNCTION
TEA PROCESSOR



微電腦全自動

Tea extractor function

1. Put tea bags

Must use tea bags (all kinds of tea bags)

2. Put hot water

Hot water in 80 -100 temperature

3. Cover the jar with the cover, and put properly onto the machine


Must cover the lid

4. Press **GREEN** button

It will stop automatically after it accomplished

Tea extraction will need 60 seconds

The tea leafes for tea
extraction must be in
tea bags




1. Put tea bag inside the jar



2. Put hot water properly



3. The extraction is in process




4. Finished extracting



shaker function T-122

3 IN 1 MULTI-FUNCTION
TEA PROCESSOR





Shaker function

1. Put the ingredients

First, put ice cube and sugar, then put tea inside.

2. Cover the jar with lid, and put the jar properly onto the machine

Must cover the lid

3. Press BLACK button


It will stop automatically after it accomplished. Shaker function only needs 3 seconds



milk froth
function
T-122

3 IN 1 MULTI-FUNCTION
TEA PROCESSOR





Milk froth maker function

1. Put the ingredients

First, put fresh milk inside the jar

2. Cover the jar with lid, and put the jar properly onto the machine

Must cover the lid

3. Press WHITE button

It will stop automatically after it accomplished. Milk froth maker function only needs 20 seconds


Put the JAR COVER and LID PROPERLY into the blender jar



DO NOT put finger when the blender is in working process



Before cleaning the machine or blender jar, remember to UNPLUG the cord



DO NOT use the machine for other purpose

DO NOT let any liquid reach inside the machine.
Ex: Water, milk, fructose, etc




DO NOT let any insects reach inside the machine




DO NOT put ice cube or ingredients until the whole jar

Maximum capacity: 800ml



over capacity



Troubleshooting and Emergency Treatment

1. When motor does not move

Possible cause: Check the jar inserted correctly or not?

Press "recovery key then unplug and re-plug the power code. (Decoding automatically)

2. Operation suddenly stopped

Possible cause: Too much amount of ingredients (ice cubes). concentration of the ingredients is too high or the viscosity is too sticky

Situation above, the amount should be reduced by half or adding more. This machine is equipped with "safety off device" help machine will automatically power off when the electricity overload, please unplug and re-plug, and then the machine will be able to use again.

Troubleshooting and Emergency Treatment

1. When motor does not move

Possible cause: Check the jar inserted correctly or not?

Press "recovery key then unplug and re-plug the power code. (Decoding automatically)

2. Operation suddenly stopped

Possible cause: Too much amount of ingredients (ice cubes). concentration of the ingredients is too high or the viscosity is too sticky

Situation above, the amount should be reduced by half or adding more. This machine is equipped with "safety off device" help machine will automatically power off when the electricity overload, please unplug and re-plug, and then the machine will be able to use again.