

Thank you for purchasing Unique Lighting Systems' Light Logic™ PLUS. The Light Logic PLUS system allows users to intuitively set up and control their lighting systems from anywhere they have internet access via the web or the Unique Lighting Light Logic app.

Setup in 3 Easy Steps!


1 Connect Hardware

2 Register

3 Configure

1 Connect Hardware

1. Connect Ethernet cable from your internet router or switch to the port on the back of the LPLUS.



2. Plug in the AC adapter.




3. LPLUS lights flash. Left LED should eventually settle on solid green.



2 Register

1. Next, register your LPLUS. Point browser to www.lightlogicplus.com.
2. Click the **Register** link.
3. Fill out all fields and press **Register**.
4. A verification email will be sent to the specified e-mail address. Click the verification link in the e-mail. You will be taken to the Light Logic website. Click the **Complete Registration** link.
5. You will be taken to the sign in page. Enter e-mail address and password then click **Sign In**.


A screenshot of the web-based sign-in interface. It features a white background with a black border. At the top, the word "Email" is followed by a text input field containing "example@email.com". Below that, the word "Password" is followed by a yellow password input field with a masked password ".....". There is a checked checkbox labeled "Stay signed in". A blue "Sign In" button is highlighted with a mouse cursor. Below the button are links for "Register" and "Forgot password". At the bottom, there is a link for "Return to Home Page".

3 Configure


Add Location

After signing in, you need to add the location of the Light Logic PLUS.

1. Click **+ Add a Location**.



2. Fill out the Name and Description fields.
3. On the Google Maps map (**Figure 1**), enter desired address into the Address field.




4. Click **Submit**.

Add Scene

A default scene is added to the Light Logic setup screen. The default scene ("Scene 1") turns on every day of the week from Dusk to 10pm. There are two ways to edit scene elements:


Scene name, description and image:

1. Click the "house" icon.
2. Enter scene name and description. You can also upload an image to replace the "house" image.



Scene days of the week and run times:

1. Click the blue pen by scene name (**Figure 2**).
2. Select which days of the week the scene will run and the times of operation for the specified days (**Figure 3**).



It is possible to have an A Schedule and a B Schedule for each scene. For example, one might want security lights to stay on longer on Friday and Saturday nights.

3. Click **Submit**.

To Add a Scene

It is possible to add additional scenes to the Light Logic PLUS (see system diagram).

1. Click the **+ Add a Scene** button.
2. Follow same steps as above. Click **Create Scene**.

To Delete a Scene

1. Press the blue pen next to the Scene name .
2. Click the red **Delete scene** link (**Figure 3**). Confirm.

Manual Scene Operation

To manually turn on or off a scene:


Click the On or Off button to the right of the scene.


To run a scene for a specific length of time, enter the desired time (in minutes) then press **On**.




Adding the Light Logic PLUS

Now you have to add the Light Logic PLUS to your Light Logic account.

1. At the computer, click the blue gear icon  by the location to add the LPLUS. From the contextual menu, select **Configure Devices**.



2. Type in the Light Logic PLUS ID. This is the "SUID" number on the sticker on the bottom of the unit.
3. Enter the Security Key also found on bottom. Click **Submit**.



4. The LPLUS should be added to the system.


Add LPCU-As to the LPLUS

At this time you can add LPCU-As.


1. Press the **Activate discovery mode** button.



2. Press the LPCU-A's button when prompted.
3. After a few seconds, the Light Logic PLUS should detect the LPCU-A. Give the detected LPCU-A a description and assign it to the desired scene.
4. Press the **Submit** button when done.



5. Repeat steps 1-4 for each LPCU-A to add.

 To add an LPRO, click **Activate Discovery Mode** then power cycle the LPRO. The LPRO may require a firmware update after adding. A notification will be shown under Hardware on the Location page.

Edit Light Logic Equipment


Click the blue pencil icon to edit LPCU-A description or change scene assignment.

Delete Light Logic Equipment

Click the blue trashcan icon to delete a LPCU-A.

Update the Firmware

If a firmware update is available for either the LPLUS or a LPCU-A, a **Manage Firmware** command will be displayed under 'Hardware' on the Location screen. Click the link to update hardware. Select the Device(s) and click **Update Firmware** to start.



Support

Check the website for FAQ and detailed instructions. To submit a help ticket, click on the **Contact** link then the **Submit a Ticket** link.

Electrical Specifications

Model Name: Light Logic Plus
Model Number: LPLUS
Dimensions: 4.4" x 3.1" x 1.2" without antenna
Unit Weight: 3.4oz (95g) without accessories
Certification: FCC, IC, UL-Listed Power Adapter
Power: 5Vdc, 1A
Port Speed: 10/100 Mbps
Operating Temp: 32 to 104°F (0-40°C)
Storage Temp: -4 to 140°F (-20 to 60°C)
Operating Humidity: 10 to 80% RH, non-condensing

FCC and IC Statements

FCC Statement - FCC ID: OF7SCG

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

In order to maintain compliance with the FCC RF exposure guidelines, this device should be installed and operated with a minimum distance of 20cm between the radiator, and the body of the operator and/or nearby persons.

Any change or modification not approved by the party responsible for compliance could void the user's authority to operate this device.

Permitted Low Gain Dipole Whip Antenna (2dBi).

IC Statement - IC: 3575A-SCG

1. Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

2. This radio transmitter has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Le présent émetteur radio (identifier le dispositif par son numéro de certification ou son numéro de modèle s'il fait partie du matériel de catégorie I) a été approuvé par Industrie Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal et l'impédance requise pour chaque type d'antenne. Les types d'antenne non inclus dans cette liste, ou dont le gain est supérieur au gain maximal indiqué, sont strictement interdits pour l'exploitation de l'émetteur.

Antenna Approved/Antenne approuvée		
Type/Type	Max. Gain/Max. Gain	Impedance/Impédance
Dipole Whip	2.0 dBi	50 Ω

3. This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

4. In order to maintain compliance with the IC RF exposure guidelines, this device should be installed and operated with a minimum distance of 20 cm between the radiator, and the body of the operator and/or nearby persons.

Afin de maintenir la conformité avec les directives d'exposition RF IC, ce dispositif doit être installé et exploité avec une distance minimale de 20 cm entre le radiateur et le corps de l'opérateur ou à proximité de personnes.

Troubleshooting

Problem	Cause	Solution
LED remains orange	Light Logic PLUS unable to get an IP address from the network's DHCP server.	Confirm the network is configured to assign IP addresses. If needed, an LPLUS can be manually configured to use a static IP address. Refer to Advanced LPLUS network setup on the website.
LED blinks green	LPLUS unable to reach the internet.	Confirm there is a valid internet connection using the same Ethernet wire if possible.

LIGHT LOGIC™ PLUS

Control your lighting system from any internet-enabled device.

