

SLGDT Lightning Arrestor

Installation Guide

A powerful inexpensive way to protect your SmartWire™ system components from lightning strikes. SmartWire™ Lightning Arrestors attach directly to the SmartWire™ 2-wire system and help dissipate static electricity generated by a nearby lightning strike. While all SmartWire™ components have optical isolators and other lightning arresting features, the Lightning Arrestor provides an important extra measure of protection.

Features

- Protects SmartWire[™] from excessive static charges created by a lightning strike.
- Connects directly to the SmartWire[™] 2-wire system for ease of installation
- Sealed and impervious to moisture, salts, fertilizers and mild chemicals
- Shock resistant
- Freeze/heat resistant (-20 to 60 C)
- · No electrical contact with the soil
- Each Lightning Arrestor protects a 300 foot radius

Electrical Specifications:

- Requires no power from SmartWire™
- Can only be connected to SmartWire[™] systems

Dimensions:


- Size: 2" x 2" x 1"
- SmartWire™ wires, red and black, 12"
- · Ground wire: green


How to Specify and Order:

SLGDT Lightning Arrestor

Installation Requirements:

- Installs directly on the SmartWire $^{\scriptscriptstyle\mathsf{TM}}$ red and black wires
- Attaches to ground rod* via green wire
- Suggested that a Lightning Arrestor be placed every 600 feet along the SmartWire™ 2-Wire path
- Can be buried directly in the soil
- One Lightning Arrestor should be within 25 ft of the SmartLine® or ProLine™ controller
- A single stub line must not exceed 50 feet without a Lightning Arrestor
- * Connect green wire to an 8' copper clad UL approved ground rod or other approved grounding method to obtain 12 ohms or less resistance.





- . Each Lightning Arrestor protects a 300 foot radius.
- 2. There shall be a Lightning Arrestor within 25' of the SmartLine® controller. A ground rod or adequate electrical safety ground may be used.
- 3. There shall be a Lightning Arrestor at the end of the SmartWire™ 2-Wire path that is the maximum distance from the SmartLine® or ProLine™ controller. If the SmartWire™ path is looped, install at the furthest point from the controller.
- 4. A stub length shall not exceed 50' without a lightning arrestor (must be within 300' of an existing Lightning Arrestor).



Help Desk: 888-484-3776

Monday - Friday 8:00 am - 5:00 pm CST

Online: support.weathermatic.com

Email: support@weathermatic.com