SUPERNOVA & NOVA

PRODUCT USER GUIDE



USER GUIDE

			Function Key Combinations
Fn	+	ESC	Hold for 5s to restore factory defaults
Fn	÷	DEL	Change Lighting Modes
Fn	÷	HOME	Solid Color Breathing Cycle
Fn	+	INS	Change Interactive Lighting Modes
Fn	÷	END	Switch to Per Key lighting mode
Fn	+	PGUP	Change Colors
Fn	+	BACK SPA	Set Per Key Lighting
Fn	+		Decrease Backlighting Animation Speed
Fn	+	Þ	Increase Backlighting Animation Speed
Fn	+		Increase Backlighting Brightness
Fn	+		Decrease Backlighting Brightness
Fn	+		Lock or Unlock Win Key
Fn	+	Y	Toggle Macro Keys (Y,U,I,O,P)
Fn	+	F1	Increase Screen Macro Key Brightness ex)
Fn	÷	F2	Decrease Screen Brightness
Fn	+	F3	Volume Down
Fn	+	F4	Volume Up
Fn	÷	F11	Set Macro Recording
Fn	+	F12	Lock All Keys
Fn	+	-	Toggle 6 key Rollover / Full key Rollover
Fn		PGDW	* Side LED Backlight Animation
Fn		Prt Sc	* Side LED RGB Mode
Fn	÷	Pause	★ Side LED Single Color Mode
Fn	+		* Side LED Decrease Speed
Fn	+		★ Side LED Increase Speed
Fn	+		 Side LED Increase Brightness
Fn	+		 Side LED Decrease Brightness
			<u> </u>





¢

DESIGNED BY HEXGEARS IN GERMANY