



# **GPS Speedometer with 3 backlight colors**

Please read and understand following notice carefully, and correctly install and operate the product before using.



- 1. Please use the product accordance with the user manual strictly.
- 2. Please do not try to disassemble the main unit and its accessories.
- 3. Waterproof from front to IP65, water can enter from rear.



- 4. Fierce vibration and strong impact may make the product failure.
- 5. Little error will be happened when measuring, within normal range.



- 6. The product need professional installation, otherwise easily get an electric shock.
- 7. Not suitable for indoor use.

# Product accessories list

**Product dimension** 


Product x 1pcs

User manual x1pcs

8 core connector with wire x1pcs


M4 nut x2pcs


mounting bracket x1pcs




# Product installation


#### 1.How to install







#### 2.Pinout orientation




# 5 The definition of indicator light

Green light flashing	Not positioned
Green light on	Positioned
Red light on	Overspeed remind

#### Product operation


At any interface, short press SET to switch 3 different backlight(RED-GREEN-BLUE)circularly. The default backlight is GREEN.








# SM-GPS97R SM-GPS97P SM-GPS97B





### Specification& Parameter

Working voltage	DC10-24V	Time format	24-hour format
Voltage accuracy	±0.5%	Housing material	ABS+Aluminum
Refresh rate	0.5\$/0.2\$	waterproof level	IP65
Speed measurement range	0-999KM/H	Display mode	37x31mmLCD
The maximum recorded driving distance	0-99999KM/H	Display window size (visible)	35x24.6mmLCD
	KM/H,MI/H,NMI/H		
Speed unit		Product weight	150g
		Dimension	Ф 64.5x66mm

# Trouble shooting

Problems	Possible reason	Solution
No display on screen	Power is connected incorrectly	Check the power wire
No display speed	Poor reception and do not receive the satellite signals	Adjust the angle
Unclear display on LCD or color changed	Norong angle of the product Lack of external battery	1.Adjust the angle 2.Check the power

# **EMR Shielding Solutions Inc.**

Address: 399 Four Valley Drive Unit 13 Concord Ontario L4K 5Y8 Canada

Canada Tel: 416-583-2005 USA Tel: 310-746-3686



